



Technical FAQ

FAS8200

Chris Lueth, NetApp

September 2016

Version 1.2

TABLE OF CONTENTS

1 FAS8200 Overview	6
What is the FAS8200 series platform?	6
Are there other FAS8200 models?	6
What are some of the new features in the FAS8200 family?	6
Does the FAS8200 come with protocols included?	6
What are the new FAS8200 model transitions?	6
2 FAS8200 Controller and Chassis	7
Which components make up the FAS8200?	7
What is the rack unit for the FAS8200 components?	7
What are the FAS8200 model numbers?	7
Which model string extensions denote HA?	7
Are the FAS8200 controllers hot swappable?	7
3 FAS8200 HA and Standalone Configurations	8
Which standalone and HA configurations are supported on the FAS8200?	8
What is the naming convention for the FAS8200 configurations?	8
Are dual-chassis HA configurations possible on the FAS8200 series?	8
Is MetroCluster available on the FAS8200 series?	8
What is the rack unit for FAS8200 configurations?	8
Which field upgrades are available with the FAS8200?	8
Does hardware-assisted takeover work on the FAS8200?	8
Are there any single points of failure in the FAS8200?	8
Does the FAS8200 series support FlexArray?	9
Does the FAS8200 support SnapLock?	9
4 FAS8200 System Features	9
How many nodes can a FAS8200 cluster have?	9
Does the FAS8200 have onboard flash?	9
How much onboard flash does the FAS8200 have?	9
Can the FAS8200 have additional onboard flash added?	9
How much memory and NVMEM does the FAS8200 have?	9
Does the FAS8200 use all of the memory and NVMEM?	9
Which type of processors and how many processing cores does the FAS8200 have?	9
Which ONTAP release is required for the FAS8200?	9
Which ONTAP build does the FAS8200 use?	10
Does the FAS8200 destage NVMEM contents to flash?	10
Does the FAS8200 encrypt NVLOG data before destaging NVMEM contents to flash?	10
What is the persistent write log feature on the FAS8200 NVMEM?	10
How does the FAS8200 use its NVMEM battery?	10
How many destages does the NVMEM battery support?	10
How long does it take for the FAS8200 NVMEM battery to charge?	10
What is the NVMEM interconnect in FAS8200 series HA configurations?	10
Does the FAS8200 have an LCD display?	10
Can I make an LED blink on the FAS8200 to identify it in a data center?	10
Does the FAS8200 series support remote management?	11
What are some of the service processor management features?	11
Is the SP connected to both the Ethernet and the serial console?	11

Is the SP an FRU like the RLM?	11
What are the recommended SP firmware levels?	11
What are the recommended BIOS levels on the FAS8200?	11
There is no NMI button on the FAS8200. How do I generate a core?	11
What are the system diagnostics in the FAS8200?	11
What is the boot medium in the FAS8200?	12
Is NetApp Volume Encryption supported on FAS8200?	12
5 FAS8200 I/O	12
What are the recommended and supported cluster interconnect ports for ONTAP 9.1 on the FAS8200?	12
What ports can be used for FC-VI connections with MetroCluster on the FAS8200?	12
What are the onboard FAS8200 ports?	13
How many slots does the FAS8200 have?	13
Which PCIe architecture does the FAS8200 use?	13
Can the FAS8200 32Gb adapter ports be set to initiator?	13
What ONTAP release is the 40GbE adapter supported in on FAS8200?	13
What is the bandwidth for the dual-port 40GbE adapter?	13
Can the 40GbE adapter be used for cluster interconnects on the FAS8200?	13
Can the 40GbE ports be broken down into separate 10GbE ports?	14
What are the port names when breaking 40GbE ports into 10GbE ports?	14
What are Unified Target Adapter 2 ports?	14
Does the FAS8200 have onboard UTA2 ports?	14
What are the configuration rules for UTA2 ports?	14
What are the UTA2 port pairs?	14
Can UTA2 ports be set to the 16Gb FC or 10GbE personality in the field?	14
Can UTA2 ports set to the 10GbE personality be mixed with 10GbE ports in a VIF?	14
What causes frame length errors on UTA2 ports in tagged VLANs?	14
What are the supported SFP+ and copper cables with onboard and adapter-based UTA2 ports?	15
Which protocols are supported on UTA2 ports?	15
Can the UTA2 port personalities be set from maintenance mode?	15
Can the UTA2 ports be used for cluster interconnects with ONTAP on the FAS8200?	15
Are UTA2 ports configured when ordering the FAS8200?	15
Can UTA2 ports be used in target or initiator mode when set to the FC personality?	15
Do the UTA2 ports autorange?	15
Do the onboard UTA2 ports provide fault tolerance?	15
Are long-reach (LR) connections supported for the onboard UTA2 ports?	15
Can UTA2 ports in the FC personality be used with tape devices?	15
Do the onboard 10GbE ports support FC over Ethernet (FCoE)?	16
Do the onboard 10GbE ports on the FAS8200 use an ASIC?	16
Do the onboard FAS8200 10GbE ports autorange down to GbE?	16
Do the onboard FAS8200 10GbE Base-T ports autorange down to GbE?	16
What are the supported cables for onboard 10GbE for onboard FAS8200 ports?	16
What are the mode and reach for the onboard 10GbE and UTA2 ports?	16
Which management interfaces does the FAS8200 have?	16
Do the e0M and SP ports support IPv6?	16
Is the external USB 2.0 port supported?	16
What is the USB device formatted for use with the FAS8200?	16
What are the allowed use cases with the FAS8200 external USB port?	17
At what speed does the FAS8200 serial console port run?	17

6	FAS8200 Storage	18
	What SAS adapters are supported in the FAS8200?	18
	Why is the X2065-R6 SAS adapter not supported in the FAS8200?	18
	How many shelves are configured with each FAS8200 node?	18
	What happens if the shelf IDs are not set and disk ownership is not assigned?	18
	What are the maximum spindle counts and capacities supported on the FAS8200 series?	18
	What are the supported flash limits on the FAS8200?	18
	What are the maximum aggregate and volume sizes on the FAS8200 series?	19
	What is the maximum number of volumes on the FAS8200?	19
	Which shelves and shelf modules are supported on the FAS8200 series?	19
	Which hard disk drives (HDDs) are supported in the FAS8200?	19
	Are all-SSD configurations supported on the FAS8200?	19
	What is the maximum shelf depth for stacks with SSDs?	19
	Does the FAS8200 use ACP cabling for out-of-band management?	19
	How is SAS storage management handled on the FAS8200?	19
7	FAS8200 Chassis Power Supplies, Weight, and Thermals	20
	What are the FAS8200 chassis dimensions?	20
	What are the FAS8200 environmental?	20
	What are the FAS8200 weights?	20
	What are the wattage and BTU ratings for the standalone FAS8200?	21
	What are the wattage and BTU ratings for FAS8200 HA pairs?	21
	Does the FAS8200 support both 110V and 220V power?	21
	Are the FAS8200 power supplies assigned to a particular controller?	21
8	Configuration Details: Supported Adapters	22
9	Configuration Details: FRUs	23
10	Sysconfig Output	24
	Revision History	27

LIST OF TABLES

Table 1) Supported FAS8200 configurations.....	8
Table 2) System memory for HA configurations.....	9
Table 3) Processing cores for HA configurations.....	9
Table 4) Recommended SP firmware levels by ONTAP release.....	11
Table 5) Recommended BIOS levels by ONTAP release.....	11
Table 6) Onboard I/O ports on FAS8200.....	12
Table 7) MetroCluster FC-VI port options.....	12
Table 8) Onboard I/O ports on FAS8200.....	13
Table 9) Supported UTA2 connectivity options.....	15
Table 10) Onboard management interfaces.....	16
Table 11) External USB port use case scenarios.....	17
Table 12) Maximum spindle counts and capacities.....	18
Table 13) Flash limits on the FAS8200 in ONTAP.....	18
Table 14) Maximum aggregate and volume sizes.....	19
Table 15) Supported shelves and shelf modules.....	19
Table 16) FAS8200 chassis dimensions.....	20
Table 17) FAS8200 environmental.....	20
Table 18) Standalone FAS8200 watts and BTU ratings.....	21
Table 19) FAS8200 HA watts and BTU ratings.....	21

Document Terms of Availability

This document is designated NetApp Confidential—Limited Use. Anyone receiving this information must have a fully executed nondisclosure agreement with NetApp.

1 FAS8200 Overview

The FAS8200 is the new midrange NetApp® storage controller. With this new midrange storage controller, NetApp has dramatically enhanced the performance and high-performance I/O density in the same 3U HA footprint. The FAS8200 supports 40GbE and 32Gb FC connections and includes the latest in SAS connectivity, the SAS 3.0 standard with 12Gb speeds. The FAS8200 also continues with the most versatile I/O interface available, the UTA2 connections that support 10GbE and 16Gb FC, and can be easily changed between these two protocols in the field. The FAS8200 also has two 10GbE connectivity options, 10GbE and 10GbE Base-T.

What is the FAS8200 series platform?

Answer: The FAS8200 series is NetApp's next-generation midrange platform.

Are there other FAS8200 models?

Answer: No, the only model is the FAS8200.

What are some of the new features in the FAS8200 family?

Answer:

- The FAS8200 features Broadwell-DE architecture
- Onboard NVMe M.2 flash
- PCIe Gen 3 architecture
- High-speed DDR4-2133 memory
- Onboard 10GbE, 16Gb FC or 10GbE UTA2, 10GbE Base-T, and SAS 3.0 12Gb ports
- External USB port can be used to recover boot media or install ONTAP® image
- Modern micro-USB serial console port runs at 115,200 baud rate

Does the FAS8200 come with protocols included?

Answer: The base software bundle for the FAS8200 includes all protocols.

What are the new FAS8200 model transitions?

Answer:

- The FAS8200 replaces the FAS8020 and FAS8040.

2 FAS8200 Controller and Chassis

Which components make up the FAS8200?

Answer: The FAS8200 components are the controller module, chassis, power supplies, possibly SFP+ modules, and adapters supported in the controller.

What is the rack unit for the FAS8200 components?

Answer: The FAS8200 chassis is 3U high.

What are the FAS8200 model numbers?

Answer: The FAS8200 is the new midrange model number.

Which model string extensions denote HA?

Answer:

- The FAS8200 single-controller model string is the FAS8200.
- The FAS8200 dual-controller model string is the FAS8200A.

Are the FAS8200 controllers hot swappable?

Answer: The FAS8200 controller is hot swappable and, it is important to note, does not require your turning off either power supply (PSU).

3 FAS8200 HA and Standalone Configurations

Which standalone and HA configurations are supported on the FAS8200?

Answer: Table 1 lists the configurations supported on the FAS8200.

Table 1) Supported FAS8200 configurations.

Configuration	Supported
Single-chassis controller with blank	Yes, with MetroCluster™ only
Single-chassis HA dual controllers	Yes

What is the naming convention for the FAS8200 configurations?

Answer: The FAS8200 is known as a single-chassis configuration. The FAS8200A is a single-chassis HA configuration.

Are dual-chassis HA configurations possible on the FAS8200 series?

Answer: No, the FAS8200 cannot span its chassis unless MetroCluster is used.

Is MetroCluster available on the FAS8200 series?

Answer: Yes. MetroCluster software is available on the FAS8200 series. FC-VI connections used in MetroCluster deployments can take advantage of the onboard UTA2 ports, eliminating the need to consume a slot with an adapter.

What is the rack unit for FAS8200 configurations?

Answer: FAS8200 chassis are 3U each.

Which field upgrades are available with the FAS8200?

Answer: All FAS8200 standalone controllers can have a second controller of the same model added to become HA.

Does hardware-assisted takeover work on the FAS8200?

Answer: Yes. Hardware-assisted takeover on the FAS8200 uses the service processor (SP), and the hardware-assisted takeover functionality is similar to that of the SP in the FAS2200, FAS2500, and FAS8000 controller families. There is more information about the SP in section 4.

Are there any single points of failure in the FAS8200?

Answer: Although the chassis backplane is not fault tolerant, there are no active components on the backplane on which controllers rely to remain in a running state. This passive backplane is a highly reliable component that is very unlikely to cause an outage on a FAS8200 series system. Reliable passive backplanes are used in almost all modular storage systems with two controllers in a single chassis as well as network switches. Also, NetApp has been shipping systems and subsystems with shared backplanes for quite some time (DS14-class disk shelves, the FAS200 series, FAS2000, FAS3100, FAS/V3200, and some FAS/V6200 and FAS8000 models) that demonstrate very high reliability of the chassis backplane.

Does the FAS8200 series support FlexArray?

Answer: Yes, the FAS8200 supports a la carte software licensing to virtualize storage arrays with FlexArray®.

Does the FAS8200 support SnapLock?

Answer: SnapLock® software is supported in ONTAP 9 and later and can be used on the FAS8200 at release as an a la carte licensing option.

4 FAS8200 System Features

How many nodes can a FAS8200 cluster have?

Answer: The FAS8200 can have up to 24 nodes with NAS and up to 12 nodes with SAN.

Does the FAS8200 have onboard flash?

Answer: Yes, the FAS8200 features onboard NVMe M.2 flash, which provides functionality similar to that provided by Flash Cache™ data caching.

How much onboard flash does the FAS8200 have?

Answer: The FAS8200 has 1TiB of flash per node and 2TiB for an HA pair.

Can the FAS8200 have additional onboard flash added?

Answer: Yes, the FAS8200 can have an additional 1TiB NVMe module of flash added per node.

How much memory and NVMEM does the FAS8200 have?

Answer: Table 2 shows system memory.

Table 2) System memory for HA configurations.

HA Pairs	Physical Memory	Total NVMEM
FAS8200A	256GB	32GB

Does the FAS8200 use all of the memory and NVMEM?

Answer: Yes. All FAS8200 models fully utilize the available memory and NVMEM at launch.

Which type of processors and how many processing cores does the FAS8200 have?

Answer: Table 3 gives processing core information.

Table 3) Processing cores for HA configurations.

HA Pairs	Architecture	Processors	Processing Cores	Processor Speed	Processor Model
FAS8200A	Broadwell-DE	2 x 64-bit 16 core	32	1.7GHz	D-1587

Which ONTAP release is required for the FAS8200?

Answer: The FAS8200 is supported starting in the ONTAP 9.1 RC1 release.

Which ONTAP build does the FAS8200 use?

Answer: The FAS8200 uses the x86_64 build. This same build supports both AMD and the latest platforms based on Intel.

Does the FAS8200 destage NVMEM contents to flash?

Answer: Yes, in the event of unexpected loss of power, the FAS8200 destages NVMEM contents to flash for a permanent, persistent write log of data not committed to disk when power was lost.

Does the FAS8200 encrypt NVLOG data before destaging NVMEM contents to flash?

Answer: Yes, all data in NVMEM is encrypted prior to being stored in flash.

What is the persistent write log feature on the FAS8200 NVMEM?

Answer: The persistent write log feature on the FAS8200 destages NVMEM contents to flash memory in the event of an unexpected loss of power. Because the NVLOG contents are stored in flash memory, they are protected permanently regardless of how long the power outage lasts. During initial bootup after power is restored, the destaged NVLOG is replayed, enabling the file system contents to include any acknowledged writes since the last consistency checkpoint (CP) to disk.

How does the FAS8200 use its NVMEM battery?

Answer: In the event of a dirty shutdown, NVMEM uses its battery to keep the NVLOG DIMMs refreshed during the reboot process. In this event the NVMEM contents are not destaged to flash. In the event of unexpected loss of power, the NVMEM battery keeps the motherboard powered up while the contents of NVMEM are destaged to flash.

How many destages does the NVMEM battery support?

Answer: A fully charged NVMEM battery can handle about 25 destage events.

How long does it take for the FAS8200 NVMEM battery to charge?

Answer: Given the new NVMEM architecture in which the entire motherboard is kept powered during the destage process, significant battery charge is consumed for a destage event. However, because a fully charged battery provides enough power for about 25 destage events, and the battery isn't used to keep the NVMEM contents refreshed for 72 hours, ONTAP should boot up normally after a destage with no pause to charge the battery.

What is the NVMEM interconnect in FAS8200 series HA configurations?

Answer: Instead of an Infiniband interface, the FAS8200 NVMEM uses nontransparent bridging (NTB) for the HA interconnect over the backplane. The NVMEM driver functionality works the same as in earlier platforms and handles the RDMA activity to keep NVMEM synchronized between the HA controllers.

Does the FAS8200 have an LCD display?

Answer: No. The FAS8200 does not have an LCD display. However, LEDs are provided on the chassis front to help determine the state of the controller. Remote management has proven to be the primary source for monitoring system information versus LCDs. Also, with the SP, the state of LEDs can be determined remotely.

Can I make an LED blink on the FAS8200 to identify it in a data center?

Answer: From the SP you can use the command `sp identify led 60` to have the fault LED on the controller rear blink for 60 seconds or toggle it on or off with `sp identify led on` and `sp identify led off`.

Does the FAS8200 series support remote management?

Answer: The FAS8200 uses the service processor (SP) used on FAS2200, FAS2500, and FAS8000 systems. The SP has all the features of RLM and BMC along with new ones that improve RASM capabilities. The new features are covered in the next few questions.

What are some of the service processor management features?

Answer: The SP performs field-replaceable unit (FRU) reporting and tracking, monitors and reports on internal sensors, reports on and can set LED states, and actively manages fan speed.

Besides the Ethernet management port interface (the external management port is shared by SP and e0M), the SP can also be accessed from the serial console by toggling with Ctrl-G. Use Ctrl-D to get back to the serial console.

Is the SP connected to both the Ethernet and the serial console?

Answer: The SP is always connected to the Ethernet and the serial console and can be accessed from either. If the SP is accessed over the Ethernet, you can toggle to the serial console with Ctrl-D. If logged in to the serial console, you can toggle in to the SP using Ctrl-G. To get back to the serial console, toggle with Ctrl-D.

Is the SP an FRU like the RLM?

Answer: No. The SP is integrated on the motherboard but runs its own kernel outside ONTAP and is always available.

What are the recommended SP firmware levels?

Answer: Table 4 lists the SP firmware levels, which depend on the ONTAP release used.

Table 4) Recommended SP firmware levels by ONTAP release.

ONTAP Release	SP Firmware Level
ONTAP 9.1 RC1	5.0

What are the recommended BIOS levels on the FAS8200?

Answer: Table 5 lists the BIOS levels, which depend on the ONTAP release used.

Table 5) Recommended BIOS levels by ONTAP release.

ONTAP Release	BIOS Level
ONTAP 9.1 RC1	11.0

There is no NMI button on the FAS8200. How do I generate a core?

Answer: The SP is required to generate a core file. After you are logged in to the SP, run the command `system core`.

What are the system diagnostics in the FAS8200?

Answer: The FAS8200 uses system-level diagnostics, or SLDIAG, in place of the older SYSDIAG on most platforms. SLDIAG is accessed using maintenance mode during bootup. If sysdiag is entered at the loader prompt, the system boots into maintenance mode.

What is the boot medium in the FAS8200?

Answer: The FAS8200 uses an mSATA USB flash in place of CompactFlash.

Is NetApp Volume Encryption supported on FAS8200?

Answer: Yes, NetApp Volume Encryption is supported on FAS8200.

5 FAS8200 I/O

What are the recommended and supported cluster interconnect ports for ONTAP 9.1 on the FAS8200?

Answer: Refer to Table 6 for cluster interconnect port requirements and recommendations.

Table 6) Onboard I/O ports on FAS8200.

Recommended	Supported
e0a, e0b (10GbE ports)	e0c, e0d (10GbE Base-T ports) ¹

- 1) 10GbE Base-T only supported as cluster interconnects with two node switchless clusters (TNSC).

What ports can be used for FC-VI connections with MetroCluster on the FAS8200?

Answer: Refer to Table 7 for cluster interconnect port requirements and recommendations.

Table 7) MetroCluster FC-VI port options.

Recommended	Supported
0e, 0f (UTA2 ports)	0g, 0h (UTA2 ports) FC-VI adapter

What are the onboard FAS8200 ports?

Answer: Refer to Table 8 for cluster interconnect port requirements and recommendations.

Table 8) Onboard I/O ports on FAS8200.

Port Type/Number per PCM	Label	Host Protocols
Mini-SAS3 (4)	0a, 0b, 0c, 0d	N/A
10GbE (2)	e0a, e0b	NFS, CIFS, iSCSI
10GbE Base-T	e0c, e0d	NFS, CIFS, iSCSI
UTA2 (4)	e0e/0e, e0f/0f, e0g/0g, e0h/0h	4/8/16Gb FC SFP: FC 10GbE SFP: FCoE, NFS, CIFS, iSCSI GbE SFP: NFS, CIFS, iSCSI
GbE e0M/SP	Wrench	N/A
Serial console (micro-USB)	IOIOI	N/A
Serial console (RJ45)	IOIOI	N/A
USB 2.0		N/A

How many slots does the FAS8200 have?

Answer: The FAS8200 has two PCIe Gen3 slots per node and four slots in an HA pair.

Which PCIe architecture does the FAS8200 use?

Answer: The FAS8200 uses the PCIe Gen 3 architecture for motherboard connectivity to onboard ports and slots.

Can the FAS8200 32Gb adapter ports be set to initiator?

Answer: No, the 32Gb FC ports only support target mode.

What ONTAP release is the 40GbE adapter supported in on FAS8200?

Answer: Support for the 40GbE adapter is targeted for ONTAP 9.1 RC2.

What is the bandwidth for the dual-port 40GbE adapter?

Answer: The total bandwidth of the two 40GbE ports is around 55Gbps.

Can the 40GbE adapter be used for cluster interconnects on the FAS8200?

Answer: No, only the onboard 10GbE, 10GbE Base-T, or UTA2 ports set to 10GbE can be used for cluster interconnects on the FAS8200.

Can the 40GbE ports be broken down into separate 10GbE ports?

Answer: Yes, one 40GbE port per adapter can be broken down into four separate 10GbE ports. In this case each of the 10GbE ports has a unique port name, depending into which port the fan out cable is plugged. When breaking a 40GbE port into four 10GbE ports, the ASIC automatically disables the second 40GbE port.

What are the port names when breaking 40GbE ports into 10GbE ports?

Answer: In this case each of the 10GbE ports has a unique port name, depending into which port the fan out cable is plugged. The 'a' 40GbE port results in 10GbE port names 'a,' 'b,' 'c,' and 'd.' The 'b' 40GbE port results in 10GbE port names 'e,' 'f,' 'g,' and 'h.' Note that you cannot use both 40GbE ports to fan out to 10GbE ports.

What are Unified Target Adapter 2 ports?

Answer: Unified Target Adapter 2 (UTA2) ports can be configured as 16Gb FC, 10GbE, or GbE. In the case of 10GbE, the UTA2 ports support FCoE, iSCSI, NFS, and CIFS; with GbE, the UTA2 ports support NFS, CIFS, and iSCSI. The previous generation of UTA ports supported only the 10GbE personality. With the addition of FC capabilities, UTA2 becomes the second generation of NetApp UTA ports.

Does the FAS8200 have onboard UTA2 ports?

Answer: Yes. The FAS8200 has four onboard UTA2 ports.

What are the configuration rules for UTA2 ports?

Answer: UTA2 ports are based on dual-port ASICs, and both ports have to be set to either 16Gb FC or 10GbE. Both ports on the X1143A-R6 share the same ASIC and have to be set to the same type: 10GbE or 16Gb FC.

When UTA2 ports are set to the FC personality, individual ports on the ASIC can be set to either target or initiator mode.

What are the UTA2 port pairs?

Answer: UTA2 port pairs on the FAS2620 are e0c/0c and e0d/0d. Port pairs on the FAS8200, FAS8060, and FAS8080 EX are first pair e0e/e0 and e0f/0f and second pair e0g/0g and e0h/0h. Both ports on the X1143A-R6 are considered port pairs, and additional X1143A-R6 adapters in other slots are their own port pair.

Can UTA2 ports be set to the 16Gb FC or 10GbE personality in the field?

Answer: Yes. The UTA2 port personality can be changed in the field using the `ucadmin` command.

See the [FAS8200 SE presentation](#) for more details about configuring UTA2 ports in the field, including using the `ucadmin` command.

Can UTA2 ports set to the 10GbE personality be mixed with 10GbE ports in a VIF?

Answer: Yes. Both ports can be mixed in the same 10GbE VIF.

What causes frame length errors on UTA2 ports in tagged VLANs?

Answer: This is an issue in the UTA2 ASIC and only affects CGMP, STP, DDP, and SNA protocols. Other more common UTA2 protocols such as NFS, CIFS, iSCSI, and FCoE use Ethernet II frame formatting and are not affected by this issue.

What are the supported SFP+ and copper cables with onboard and adapter-based UTA2 ports?

Answer: See Table 9 for supported UTA2 connectivity options.

Table 9) Supported UTA2 connectivity options.

	Onboard UTA2 Ports		1GbE
	16Gb FC	10GbE	
SFP+	X6596-R6	X6589A-R6	X6567-R6 (optical) X6568-R6 (RJ-45)
Cables	See Hardware Universe (HWU)		

Which protocols are supported on UTA2 ports?

Answer: The onboard and adapter-based UTA2 ports support FC and, when set to the 10GbE personality, FCoE, iSCSI, NFS, and CIFS.

The GbE SFP transceivers support NFS, CIFS, and iSCSI.

Can the UTA2 port personalities be set from maintenance mode?

Answer: Yes. You can set the port personalities in maintenance mode.

Can the UTA2 ports be used for cluster interconnects with ONTAP on the FAS8200?

Answer: Yes. The UTA2 ports are supported for cluster interconnects.

Are UTA2 ports configured when ordering the FAS8200?

Answer: Yes. When quoting FAS8200 systems, you are asked for onboard and adapter-based UTA2 port personality and, in the case of Ethernet, if you need SFP+ or twinax copper cables. Manufacturing then sets the port personality and inserts the correct SFP+.

Can UTA2 ports be used in target or initiator mode when set to the FC personality?

Answer: Yes. Onboard and adapter-based UTA2 ports can be configured as target or initiator.

Do the UTA2 ports autorange?

Answer: UTA2 ports set to FC personality ports autorange across 16/8/4Gbps speeds but do not work with 1Gb or 2Gb FC speeds. UTA2 ports set to the 10GbE personality do not autorange down to GbE speeds but do support GbE speeds with the SFPs shown in Table 9.

Do the onboard UTA2 ports provide fault tolerance?

Answer: The FAS8200 has two UTA2 ASICs. Port pairs are e0c/0c and e0d/0d and share an ASIC, and port pairs e0e/0e and e0f/0f share the second ASIC.

Are long-reach (LR) connections supported for the onboard UTA2 ports?

Answer: Yes, an SFP+ is available for LR on the FAS8200. The part number is X65403, and the description is CONN, SFP, 16Gb, FC, LR, 10km.

Can UTA2 ports in the FC personality be used with tape devices?

Answer: Direct connection to tape drives with UTA2 ports is supported on HP, Quantum, and Tandberg tape devices. IBM tape devices requires an FC switch between the UTA2 port and tape drive.

Do the onboard 10GbE ports support FC over Ethernet (FCoE)?

Answer: No. Onboard 10GbE ports do not work for FCoE uses.

Do the onboard 10GbE ports on the FAS8200 use an ASIC?

Answer: No, the onboard 10GbE ports connect to interfaces on the Broadwell-DE processor.

Do the onboard FAS8200 10GbE ports autorange down to GbE?

Answer: No. The onboard 10GbE ports do not autorange but can be set to GbE speed by using the SFP options shown in Table 9.

Do the onboard FAS8200 10GbE Base-T ports autorange down to GbE?

Answer: Yes, the onboard 10GbE Base-T ports can autorange to GbE.

What are the supported cables for onboard 10GbE for onboard FAS8200 ports?

Answer: For the latest about supported FAS8200 cables, refer to the [Hardware Universe \(HWU\)](#).

What are the mode and reach for the onboard 10GbE and UTA2 ports?

Answer: The onboard GbE and 10GbE ports are short-reach multimode ports.

Which management interfaces does the FAS8200 have?

Answer: See Table 10 for FAS8200 management interfaces.

Table 10) Onboard management interfaces.

Active-Active	Micro-USB Serial Console	RJ-45 Serial Console	Management SP/e0M (Wrench)
All models	2		2 x GbE (e0M) 2 x 10/100Mb SP ¹

¹ The SP port links to the external switch at GbE speed, but the internal path is limited to 10/100Mb.

Do the e0M and SP ports support IPv6?

Answer: Yes. Both e0M and SP support IPv6.

Is the external USB 2.0 port supported?

Answer: Yes, the external USB port can be used to boot ONTAP if the onboard boot media has failed, to install a particular release of ONTAP, or install a firmware service image. The external USB port is only enabled during these activities, and its activation is based on specific commands.

What is the USB device formatted for use with the FAS8200?

Answer: The USB device needs to have FAT32 formatting to use on the external USB port.

What are the allowed use cases with the FAS8200 external USB port?

Answer: Table 11 shows use cases in which the external USB port can be used.

Table 11) External USB port use case scenarios.

Scenario	Prerequisites	Command
Perform boot device recovery from loader prompt	• USB 2.0 device formatted to FAT32 with correct ONTAP netboot.tgz and image.tgz image • Not hot pluggable, need to boot to loader prompt after USB device is inserted into external USB port	• boot_recovery using the netboot image at the loader prompt • Select appropriate ONTAP image at the boot menu
Fetch ONTAP software for installation	USB 2.0 device formatted to FAT32 with correct ONTAP image	• system node image update/get • Command has an additional option to fetch ONTAP from USB device
Fetch service image for firmware update	USB 2.0 device formatted to FAT32 with correct service image	• system node firmware download • Command has an additional option to fetch ONTAP from USB device

At what speed does the FAS8200 serial console port run?

Answer: The FAS8200 serial console ports run at 115K baud rate.

6 FAS8200 Storage

What SAS adapters are supported in the FAS8200?

Answer: The only supported SAS adapter in the FAS8200 is the X2069-R6.

Why is the X2065-R6 SAS adapter not supported in the FAS8200?

Answer: With the onboard 12Gb SAS ports, system health monitors are degraded by having 6Gb SAS storage paths in the system. The X2069-R6 does support 6Gb SAS speeds and can be used with DS2246, DS4246, and DS4486 shelves.

How many shelves are configured with each FAS8200 node ?

Answer: FAS8200 systems are configured in the factory with only one shelf per node (node + 1 shelf). Additional shelves are not configured and arrive having shelf IDs set to '0' and no disk ownership assigned.

What happens if the shelf IDs are not set and disk ownership is not assigned?

Answer: If there are conflicting shelf IDs, ONTAP assigns a soft shelf ID based on the shelf serial number. If the case concerns disk ownership, provided there are disks on the stack with ownership already set, ONTAP automatically handles assigning the remaining unowned disks. Because one shelf per node has disk ownership set, orders with one stack per node should not need disk ownership assignment.

What are the maximum spindle counts and capacities supported on the FAS8200 series?

Answer: Table 12 shows maximum spindle counts and capacities.

Table 12) Maximum spindle counts and capacities.

Standalone and HA	Maximum Spindles SAS/SATA	Maximum SSDs	Maximum SSD + SAS and/or SATA
FAS8200	480	480	480

What are the supported flash limits on the FAS8200?

Answer: Table 13 shows these limits.

Table 13) Flash limits on the FAS8200 in ONTAP.

	Flash Limits
NVMe M.2 onboard Flash Cache	Default 1TB per node Maximum 2TB per node
Maximum onboard flash + Flash Pool™ cache (HA and standalone)	48TiB

What are the maximum aggregate and volume sizes on the FAS8200 series?

Answer: Table 14 shows the maximum aggregate and volume sizes.

Table 14) Maximum aggregate and volume sizes.

	FAS8200
Maximum number of volumes	1,000
Maximum aggregate size	400TB
Maximum volume size	100TB
Minimum root volume size	350GB

What is the maximum number of volumes on the FAS8200?

Answer: The FAS8200 supports up to 1,000 volumes.

Which shelves and shelf modules are supported on the FAS8200 series?

Answer: Table 15 shows the supported shelves and shelf modules.

Table 15) Supported shelves and shelf modules.

Shelf	Shelf Module
DS224C	IOM12
DS212C	IOM12
DS2246	IOM6 IOM12
DS4246	IOM6 IOM12

Which hard disk drives (HDDs) are supported in the FAS8200?

Answer: Any disk supported in the shelves listed in Table 12 in ONTAP 9.x is supported on the FAS8200 series. For the latest about supported drive options on the FAS8200, see the [Hardware Universe \(HWU\)](#).

Are all-SSD configurations supported on the FAS8200?

Answer: Yes, all-SSD configurations are supported on the FAS8200.

What is the maximum shelf depth for stacks with SSDs?

Answer: The maximum shelf depth for stacks containing SSDs is four. This applies to pure SSD stacks and Flash Pool stacks with SSD and HDD disks.

Does the FAS8200 use ACP cabling for out-of-band management?

Answer: No, there is no locked wrench port on the FAS8200 for traditional ACP cabling.

How is SAS storage management handled on the FAS8200?

Answer: Starting in ONTAP 9, SAS storage management is handled in band over the SAS cables.

7 FAS8200 Chassis Power Supplies, Weight, and Thermals

What are the FAS8200 chassis dimensions?

Answer: For the most comprehensive information about FAS8200 dimensions and weights across various configuration options, refer to the [Hardware Universe \(HWU\)](#).

Table 16) FAS8200 chassis dimensions.

Dimension	Metric	English
Height	3U	
Height (measured)	13cm	5"
Width	44.7cm	17.6" (fits 19" rack)
Chassis depth	60.8cm	23.9"
With cable management	73.5cm	28.9"

What are the FAS8200 environmentals?

Answer: For the most comprehensive information about FAS8200 environmental details, refer to the [Hardware Universe \(HWU\)](#).

Table 17) FAS8200 environmentals.

	Operational	Storage	Transit
Temperature Range	From 41°F up to 113°F (5°C up to 45°C)	From -40°F up to 158°F (-40°C up to 70°C)	From -40°F up to 158°F (-40°C up to 70°C)
Relative Humidity	From 8% up to 90%	From 10% up to 95%	From 10% up to 95%
Altitude	Up to 9999ft (3048m)	Up to 39999ft (12192m)	Up to 39999ft (12192m)

What are the FAS8200 weights?

Answer: For the most comprehensive information about FAS8200 weight information across various configuration options, refer to the [Hardware Universe \(HWU\)](#).

The FAS8200 standalone is 67.46 pounds (30.6kg), and the HA is 78.92 pounds (35.8kg).

What are the wattage and BTU ratings for the standalone FAS8200?

Answer: For the most comprehensive information about FAS8200 wattage and BTU ratings across various configuration options, refer to the [Hardware Universe \(HWU\)](#).

Table 18) Standalone FAS8200 watts and BTU ratings.

	110V		220V	
	Worst Case	Typical	Worst Case	Typical
Amps (A)	4	3.15	1.97	1.55
Watts (W)	392	308	385	302
BTU	1,338	1,052	1,314	1,031

What are the wattage and BTU ratings for FAS8200 HA pairs?

Answer: For the most comprehensive information about FAS8200 wattage and BTU ratings across various configuration options, refer to the [Hardware Universe \(HWU\)](#).

Table 19) FAS8200 HA watts and BTU ratings.

	110V		220V	
	Worst Case	Typical	Worst Case	Typical
Amps (A)	6.49	5.65	3.19	2.77
Watts (W)	636	553	624	542
BTU	2,171	1,888	2,130	1,850

Does the FAS8200 support both 110V and 220V power?

Answer: Yes. Both voltage levels are supported on the FAS8200.

Are the FAS8200 power supplies assigned to a particular controller?

Answer: No. The two power supplies are assigned to the FAS8200 chassis.

8 Configuration Details: Supported Adapters

For the latest information about FAS8200 FRUs, refer to the [Hardware Universe \(HWU\)](#).

Adapter Cards

Adapters are shown in top to bottom priority for load order, slot priority is 1, 2

Card Category	Description	Marketing PN	Mfg PN
MetroCluster	2p 16Gb FC-VI SFP+	X1928A-R6	111-00941
Networking (high performance)	2p 10GbE NIC Cu/Op	X1117A-R6	111-00754
			111-01232
	NIC, 2x40GbE, QSFP	X1144A	111-03380
	2p 16Gb/10Gb UTA2 Cu/Op	X1143A-R6	111-00910
	2p 10Gb NIC Cu	X1120A-R6	111-01688
Block access (high performance)	2-Port FCP Target 32Gb PCIe w/SFP+	X1134A	111-03249
	2p 16Gb/10Gb UTA2 Cu/Op	X1143A-R6	111-00910
	4p 16Gb FC SFP+	X1133A-R6	111-02451
	4p 8Gb FC Op	X1132A-R6	111-00481
Performance acceleration	NVME, FLASH, 512GB	X3310A	111-03065
	NVME, FLASH, 1TB	X3311A	111-03066
Storage	2p 16Gb/10Gb UTA2 Cu/Op	X1143A-R6	111-00910
	4p 12Gb SAS Cu	X2069-R6	111-02026
	4p 16Gb FC SFP+	X1133A-R6	111-02451
	4p 8Gb FC Op	X1132A-R6	111-00481
	4p 4Gb FC Op	X2054A-R6	111-00285
Block access	4p 4Gb FC Op	X1130A-R6	111-00416
Networking	4p 1GbE NIC Cu	X1049C-R6	111-01034
	4p 1GbE NIC Op	X1048A-R6	111-00909
Tape	2p 16Gb/10Gb UTA2 Cu/Op	X1143A-R6	111-00910
	4p 16Gb FC SFP+	X1133A-R6	111-02451
	4p 8Gb FC Op	X1132A-R6	111-00481
	4p 12Gb SAS Cu	X2069-R6	111-02026
	4p 4Gb FC Op	X2054A-R6	111-00285

9 Configuration Details: FRUs

For the latest information about FAS8200 FRUs, refer to the [Hardware Universe \(HWU\)](#).

Field Replaceable Units

FRU Unit Type	Marketing PN	Description
Battery	X1847-R6	Lithium System Battery CR2032, R6
	X3150A	R7, NV, BATT, 4CELL, HiAh, HOLDER
Cable management guide	X3321A	SUB ASSY, SM, BKT, CBL MGMT SET
Chassis	X3160A	R7, CHAS ASSY, W/ MIDPLANE/FAN/PSU
Controller blank	X3118-R6	Blanking Panel, SYS CNTR
Fan	X8535-R6	Fan Assembly, FAS/V32X0, SA320, FAS8020
Memory module	X3223A	RDIMM, 32GB, ECC, FAS8200, A300
	X3311A-C	Flash Cache, 1TB, -C
mSATA	X3320A	R7, DRIVE, SSD, 128GB, mSATA
Processor controller module (PCM)	X3171A	SUB ASSY, CONTROLLER, MEM
	X3172A	R7, SUB ASSY, CONTROLLER, NO MEM
PSU	PH-FAS800__PSU	PH-FAS8200 - PWR SPLY, 1300W, AC, PLATINUM, FAS8200
Rail kit	X5515A-R6	Kit, 2-Post (Round) or 4-Post (Square), 24"-32" Rail
	X5525A-R6	Kit, 2-Post, Round-Hole
	X5526A-R6	Kit, 4-Post, Square-Hole, 24"-32" Rail
	X5529A-R6	Kit, 4-Post, Swift, Square-Hole, 24"-32" Rail
	X877B-R6	Rail Kit II, NetApp Cabinet, R6
	X8783A-R6	Rail Kit III, NetApp Cabinet, R6
Transceiver	X65400A-R6	XCVR, QSFP, MPO, Optical, 6Gb, SAS (SAS6Gb)
	X65402	Conn, QSFP, 40GbE SR, for NetApp controller cluster (Ethernet 40Gb)
	X65403	CONN, SFP, 16Gb FC, LR, 10km (FC-VI, Fibre Channel 16Gb, Fibre Channel 4/8/16Gb)
	X6567-R6	SFP Optical 1GB Shortwave Multimode (Ethernet 1/10Gb, Fibre Channel 4/8/16Gb)
	X6568-R6	SFP Copper 1GB RJ-45 (Ethernet 1/10Gb, Fibre Channel 4/8/16Gb)
	X6569-R6	XCVR, SFP+, Optical, 10GbE, Shortwave, X1117A (Ethernet 10Gb)
	X6589-R6	XCVR, SFP+, Optical, 10GbE, Shortwave (Ethernet 1/10Gb, Fibre Channel 4/8/16Gb)
	X6596-R6	XCVR, SFP+, Optical, 16Gb, FC, Shortwave (Ethernet 1/10Gb, Fibre Channel 16Gb, Fibre Channel 4/8/16Gb, Fibre Channel 4Gb, Fibre Channel 8Gb)
	X6599A-R6	XCVR, SFP+, Optical, 10GbE, Shortwave (Ethernet 1/10Gb, Ethernet 10Gb, Fibre Channel 4/8/16Gb)
	X6600A-R6	XCVR, SFP+, Optical, 10GbE, Shortwave, X1143A (Ethernet 10Gb)
	X6601A-R6	XCVR, SFP+, Optical, 16Gb, FC, Longwave (Ethernet 1/10Gb, FC-VI, Fibre Channel 16Gb, Fibre Channel 4/8/16Gb)
	X6602A-R6	XCVR, SFP+, Optical, 16Gb, FC, Shortwave (Fibre Channel 16Gb, Fibre Channel 4Gb, Fibre Channel 8Gb)
	X6603A	SFP+ Optical, 32Gb FC Shortwave (Fibre Channel 8/16/32)

10 Sysconfig Output

```
FAS8200-230-51-52::> run local version
NetApp Release 9.1: Tue Aug 2 15:23:08 IST 2016 <1d>
```

```
FAS8200-230-51-52::> run local sysconfig -av
NetApp Release 9.1: Tue Aug 2 15:23:08 IST 2016
System ID: 0537002848 (FAS8200-230-51); partner ID: 0537002860 (FAS8200-230-52)
System Serial Number: 941621000062 (FAS8200-230-51)
System Rev: 81
System Storage Configuration: Multi-Path HA
System ACP Connectivity: Inband Active
All-Flash Optimized: false
Backplane Part Number: 111-02495
Backplane Rev: 81
Backplane Serial Number: 021617008455
slot 0: System Board 1.7 GHz (System Board XXII 81)
    Model Name: FAS8200
    Part Number: 111-02493
    Revision: 81
    Serial Number: 021620006566
    BIOS version: 11.0X14
    Loader version: 6.0X22
    Processors: 16
    Processor type: Intel(R) Xeon(R) CPU D-1587 @ 1.70GHz
    Memory Size: 131072 MB
    Memory Attributes: Bank Interleaving
                        Hoisting
                        Rank Interleaving
                        Channel Interleaving
                        Chipkill ECC
    NVMEM Size: 8190 MB of Main Memory Used
    Controller: A
    PCIE Switch 0: id 0 519 1.04
    PCIE Switch 1: id 1 519 1.08
Service Processor
    Firmware Version: 5.0X23
    Mgmt MAC Address: 00:A0:98:A4:F3:AF
    Ethernet Link: up, full duplex, auto-neg complete
    Using DHCP: no
IPv4 configuration:
    IP Address: 10.72.231.51
    Netmask: 255.255.254.0
    Gateway: 10.72.230.1
IPv6 configuration: Disabled
[Service Processor cached network information determined at Thu Aug 11 06:04:23 GMT 2016]
slot 0: Internal 10/100/1000 Ethernet Switch
    Firmware Version: Version11 SB_XXII ETHSW RZL
    Wrench: auto-1000t-fd-up
    Device Type: 88E6176
slot 0: Gigabit Ethernet I210
    e0M MAC Address: 00:a0:98:a4:f3:ad (auto-1000t-fd-up)
    Device Type: 1533
    Firmware Version: 3.25-5.4 0x800005CD
slot 0: 10 Gigabit Ethernet Controller IX5-SFP+
    e0a MAC Address: 00:a0:98:a4:f3:9d (auto-10g_sr-fd-up)
    e0b MAC Address: 00:a0:98:a4:f3:9e (auto-10g_sr-fd-up)
    Device Type: X550EM
    Firmware Version: 0.86-5.1 (20150807-0501)
slot 0: 1/10 Gigabit Ethernet Controller IX4-T
    e0c MAC Address: 00:a0:98:a4:f3:9f (auto-10g_t-fd-up)
    e0d MAC Address: 00:a0:98:a4:f3:a0 (auto-10g_t-fd-up)
    Device Type: X550
    Firmware Version: 1.0-5.1
slot 0: 1G/10G Ethernet Controller CNA EP 8324
    (Multiple Dual-port, QLogic CNA 8324(8362) rev. 2)
    e0e MAC Address: 00:a0:98:a4:f3:a1 (auto-10g_sr-fd-up)
    e0f MAC Address: 00:a0:98:a4:f3:a2 (auto-unknown-down)
    e0g MAC Address: 00:a0:98:a4:f3:a3 (auto-unknown-down)
    e0h MAC Address: 00:a0:98:a4:f3:a4 (auto-unknown-down)
    Device Type: EP8324N
```

```

NIC Firmware rev: 5.4.56.0
slot 0: PLX DMA Engine 2 (PLX87d0)
State: Active
slot 0: Interconnect HBA: Generic OFED Provider
Port Name: ib0a
GID: fe80:0000:0000:0000:0000:0000:0104
Base LID: 0x104
Active MTU: 8192
slot 0: NTB Interconnect i0 (PLX87b0)
Max HW Data Rate: PCIe Gen 3 x 8
HW Data Rate: PCIe Gen 3 x 8
SW Data Rate: PCIe Gen 3 x 8
Logical Link: Up
Port State: Enabled
slot 0: SAS Host Adapter 0a (PMC-Sierra PM8072 rev. C, SAS, <UP>)
Firmware rev: 03.07.11.00
Base WWN: 5:00a098:0038976:50
Phy State: [12] Enabled, 6.0 Gb/s
[13] Enabled, 6.0 Gb/s
[14] Enabled, 6.0 Gb/s
[15] Enabled, 6.0 Gb/s
Mini-SAS HD Vendor: Molex Inc.
Mini-SAS HD Part Number: 112-00430+A0
Mini-SAS HD Type: Passive Copper (unequalized) 2m ID:00
Mini-SAS HD Serial Number: 520830436
ID Vendor Model FW Size

```

(Note - disk information removed to save space)

```

Shelf 0: DS4486 Firmware rev. IOM6 A: 0190 IOM6 B: 0190
Shelf 1: DS2246 Firmware rev. IOM6 A: 0190 IOM6 B: 0190
slot 0: SAS Host Adapter 0b (PMC-Sierra PM8072 rev. C, SAS, <UP>)
Firmware rev: 03.07.11.00
Base WWN: 5:00a098:0038976:54
Phy State: [8] Enabled, 6.0 Gb/s
[9] Enabled, 6.0 Gb/s
[10] Enabled, 6.0 Gb/s
[11] Enabled, 6.0 Gb/s
Mini-SAS HD Vendor: Molex Inc.
Mini-SAS HD Part Number: 112-00430+A0
Mini-SAS HD Type: Passive Copper (unequalized) 2m ID:00
Mini-SAS HD Serial Number: 520830403
ID Vendor Model FW Size

```

(Note - disk information removed to save space)

```

Shelf 0: DS4486 Firmware rev. IOM6 A: 0190 IOM6 B: 0190
Shelf 1: DS2246 Firmware rev. IOM6 A: 0190 IOM6 B: 0190
slot 0: SAS Host Adapter 0c (PMC-Sierra PM8072 rev. C, SAS, <OFFLINE (hard)>)
Firmware rev: 03.07.11.00
Base WWN: 5:00a098:0038976:58
Phy State: [0] Disabled
[1] Disabled
[2] Disabled
[3] Disabled
QSFP Vendor: not available
QSFP Part Number: not available
QSFP Type: not available
QSFP Serial Number: not available
slot 0: SAS Host Adapter 0d (PMC-Sierra PM8072 rev. C, SAS, <OFFLINE (hard)>)
Firmware rev: 03.07.11.00
Base WWN: 5:00a098:0038976:5c
Phy State: [4] Disabled
[5] Disabled
[6] Disabled
[7] Disabled
QSFP Vendor: not available
QSFP Part Number: not available
QSFP Type: not available
QSFP Serial Number: not available

```

```

slot 0: Fibre Channel Target Host Adapter 0e
(QLogic CNA 8324 (8362) rev. 2, <LINK NOT CONNECTED>)
  Firmware rev:      8.5.1
  Flash rev:         5.0.2
  Host Port Addr:    000000
  FC Nodename:       50:0a:09:80:80:12:03:60 (500a098080120360)
  FC Portname:       50:0a:09:82:80:12:03:60 (500a098280120360)
  Connection:        No link
  Switch Port:       Unknown
  SFP Vendor Name:    AVAGO
  SFP Vendor P/N:     AFBR-709SMZ-NA2
  SFP Vendor Rev:     G4.1
  SFP Serial No.:    AD153030RG3
  SFP Connector:      LC
  SFP Capabilities:   10 Gbit/Sec
slot 0: Fibre Channel Target Host Adapter 0f
(QLogic CNA 8324 (8362) rev. 2, <LINK NOT CONNECTED>)
  Firmware rev:      8.5.1
  Flash rev:         5.0.2
  Host Port Addr:    000000
  FC Nodename:       50:0a:09:80:80:12:03:60 (500a098080120360)
  FC Portname:       50:0a:09:81:80:12:03:60 (500a098180120360)
  Connection:        No link
  Switch Port:       Unknown
slot 0: Fibre Channel Target Host Adapter 0g
(QLogic CNA 8324 (8362) rev. 2, <LINK NOT CONNECTED>)
  Firmware rev:      8.5.1
  Flash rev:         5.0.2
  Host Port Addr:    000000
  FC Nodename:       50:0a:09:80:80:12:03:60 (500a098080120360)
  FC Portname:       50:0a:09:84:80:12:03:60 (500a098480120360)
  Connection:        No link
  Switch Port:       Unknown
slot 0: Fibre Channel Target Host Adapter 0h
(QLogic CNA 8324 (8362) rev. 2, <LINK NOT CONNECTED>)
  Firmware rev:      8.5.1
  Flash rev:         5.0.2
  Host Port Addr:    000000
  FC Nodename:       50:0a:09:80:80:12:03:60 (500a098080120360)
  FC Portname:       50:0a:09:83:80:12:03:60 (500a098380120360)
  Connection:        No link
  Switch Port:       Unknown
slot 0: Intel BDW SATA Controller u0a (0x50511000)
boot0 Micron M600 MTFDDAT128MBF      MU05 122104MB 512B/sect
(16131225115A)
slot 0: Intel USB EHCI Adapter u0b (0x50512000)
slot 3: Flash Cache NVMe
  Serial Number:      S2UWNAAH400058
  Part Number:        110-00466
  Hardware Revision:   A0
  Firmware Version:    NA00
  Model Name:          X3311A
  Capacity:            1024 GB
  Vendor Name:         Samsung
  State:               ok
slot 4: Flash Cache NVMe
  Serial Number:      S2UWNAAH400040
  Part Number:        110-00466
  Hardware Revision:   A0
  Firmware Version:    NA00
  Model Name:          X3311A
  Capacity:            1024 GB
  Vendor Name:         Samsung
  State:               ok

```

FAS8200-230-51-52::>

Revision History

Revision	Date	Comment
1.0	September 2016	Initial release
1.1	September 2016	Update cluster interconnect support with 10GbE Base-T in table 6 Added support information about NVE in section 4
1.2	September 2016	Added supported ONTAP release details for 40GbE adapter in section 5. Removed UTA2 support with cluster interconnects in table 6

Refer to the [Interoperability Matrix Tool \(IMT\)](#) on the NetApp Support site to validate that the exact product and feature versions described in this document are supported for your specific environment. The NetApp IMT defines the product components and versions that can be used to construct configurations that are supported by NetApp. Specific results depend on each customer's installation in accordance with published specifications.

Copyright Information

Copyright © 1994–2016 NetApp, Inc. All rights reserved. Printed in the U.S. No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Software derived from copyrighted NetApp material is subject to the following license and disclaimer:

THIS SOFTWARE IS PROVIDED BY NETAPP "AS IS" AND WITHOUT ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, WHICH ARE HEREBY DISCLAIMED. IN NO EVENT SHALL NETAPP BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

NetApp reserves the right to change any products described herein at any time, and without notice. NetApp assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by NetApp. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of NetApp.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark Information

NetApp, the NetApp logo, Go Further, Faster, AltaVault, ASUP, AutoSupport, Campaign Express, Cloud ONTAP, Clustered Data ONTAP, Customer Fitness, Data ONTAP, DataMotion, Flash Accel, Flash Cache, Flash Pool, FlashRay, FlexArray, FlexCache, FlexClone, FlexPod, FlexScale, FlexShare, FlexVol, FPolicy, GetSuccessful, LockVault, Manage ONTAP, Mars, MetroCluster, MultiStore, NetApp Fitness, NetApp Insight, OnCommand, ONTAP, ONTAPI, RAID DP, RAID-TEC, SANshare, SANtricity, SecureShare, Simplicity, Simulate ONTAP, SnapCenter, SnapCopy, Snap Creator, SnapDrive, SnapIntegrator, SnapLock, SnapManager, SnapMirror, SnapMover, SnapProtect, SnapRestore, Snapshot, SnapValidator, SnapVault, SolidFire, StorageGRID, Tech OnTap, Unbound Cloud, vFiler, WAFL, and other names are trademarks or registered trademarks of NetApp, Inc. in the United States and/or other countries. All other brands or products are trademarks or registered trademarks of their respective holders and should be treated as such. A current list of NetApp trademarks is available on the web at <http://www.netapp.com/us/legal/netapptmlist.aspx>.