

Data ONTAP® commands	
Management commands	
fc {start stop}	Starts or stops the FC or iSCSI service on the storage system.
iscsi {start stop}	
fc config [<i>adapter</i> [up down] [<i>partner</i> { <i>adapter</i> None} - <i>partner</i>] [<i>mediatype</i> {ptp auto loop}] [<i>speed</i> {1 2 4 auto}]]	Configures the FC target adapters on the storage system. Not all versions of Data ONTAP support 4-gigabyte speed. Enter fc config with no arguments to display adapter information.
fc show adapter [-v] [<i>adapter</i>]	Displays information about target adapters on the storage system.
fc show cfmode	Displays the cfmode of a storage system in an active/active configuration.
fc show initiator [-v] [<i>adapter</i>]	Displays information about initiators connected to the storage system.
license [add <i>code</i>]	Displays or adds storage system license codes. Use this command to verify that both FC and iSCSI are licensed on the storage system.
iscsi config [<i>adapter</i> [up down]]	Configures the iSCSI target adapter status as up or down. Omit <i>up</i> or <i>down</i> to display configurable information. Omit <i>adapter</i> to display all information. Note: This command is used only in Data ONTAP 7.0.x.
iscsi nodename [<i>new_nodename</i>]	Displays or sets the iSCSI target node name.
iscsi alias [-c <i>new_alias</i>]	Displays, clears, or sets a new alias for the iSCSI target node name. Note: This command is not available in Data ONTAP 7.0.x and earlier.
iscsi show adapter [<i>adapter...</i>]	Displays target adapter information for specified logical adapters. Note: This command is used only in Data ONTAP 7.0.x.
iscsi initiator show	Displays information about initiators connected to the target.
ifconfig [-a <i>interface</i>]	Displays or configures network parameters for the specified interface. Use -a to display all network interfaces.
Target status, performance, and troubleshooting commands	
{ fc iscsi } status	Displays the status of the FC or iSCSI service on the storage system.
sysstat {-i -f} [<i>interval</i>]	Displays iSCSI (-i) or FC (-f) performance statistics. <i>interval</i> is the reporting interval, in seconds; The default value is 15 seconds.
fc stats [-z] [<i>adapter</i>]	Displays statistics for the specified FC target adapter. Use -z to clear the statistics.
fc stats -i <i>interval</i> [-c <i>count</i>] [-a <i>adapter</i>]	Displays FC performance statistics over a specified interval. <i>interval</i> is the reporting interval, in seconds. Specify <i>adapter</i> , or use -a to display statistics for all FC target adapters.
lun stats [-z] [-o] [-a <i>lun_path</i>]	Displays block access statistics for the specified LUN. Use -z to clear the statistics. Use -o to display extended statistics or -a to display statistics for all LUNs. (FC or iSCSI)
lun config_check [-S] [-s -v]	Performs several checks on the lun/igroup/fcp configuration of the storage system. Note: This command is used only in Data ONTAP 7.1 or later. (FC specific)
iscsi stats [-z]	Displays numbers of iSCSI PDUs and CDBs, and error statistics.
ifstat [-z] -a <i>interface</i>	Displays device-level statistics for the specified network interface. Use -z to clear the statistics. Use -a to display statistics for all interfaces. (iSCSI specific)
iSCSI software target management commands	
iscsi interface show [-a <i>interface...</i>]	Displays the network interfaces that are enabled on iSCSI traffic.
iscsi interface enable {-a <i>interface...</i> }	Enables the use of specified network interfaces by iSCSI traffic. Use -a to enable all. Note: It is best not to enable gigabit Ethernet interfaces for iSCSI traffic.
iscsi interface disable [-f] {-	Disables the use of specified network interfaces for iSCSI traffic.

Linux® Host Utilities 5.3 Quick Command Reference

a <i> interface...}</i>	Use -f to force the termination of current sessions Use -a to disable all.
iscsi session show [-v] <i>adapter [session_num]</i>	Displays the status of one session, or for all sessions and connections associated with a specified logical adapter if no session number is specified. Note: This command is used only in Data ONTAP 7.0.x.
iscsi session show [-v] <i>[session_num]</i> iscsi connection show [-v] <i>[sess conn]</i>	Displays the status of one session or connection or for all if no session number or connection number is specified. Note: This command is not available in Data ONTAP 7.0.x and earlier.
iscsi tpgroup create [-f] [-t <i>tpgtag]</i> <i>tpgroup_name [interface ...]</i>	Creates the user-defined target portal group, which is needed for multi-connection sessions. All connections for a session must use interfaces in the same target portal group. Note: This command is not available in Data ONTAP 7.0.x and earlier.
iSCSI authentication (CHAP) management commands	
iscsi security add -i <i>initiator</i> -s CHAP -p <i>inpassword -n inname [-o outpassword -m outname]</i>	Defines the authentication method for the specified initiator. For <i>initiator</i> , use node name in IQN format. Note that <i>inname</i> on a storage system is set to the outgoing user name on a host. Use -o and -m for bidirectional CHAP.
iscsi security default -s CHAP -p <i>inpassword -n inname [-o outpassword -m outname]</i>	Sets the default authentication method, user names, and passwords for all initiators not specifically configured.
LUN and igroup management commands	
lun setup	Enables interactive LUN creation. Combines the <code>lun create</code> , <code>igroup create</code> , <code>igroup add</code> , and <code>lun map</code> command functions. <i>(FC or iSCSI)</i>
lun create -s <i>size</i> -t linux <i>lun_path</i>	Creates LUNs manually. Enter <i>size</i> as integer bytes with one of the following suffixes: m (megabytes), g (gigabytes), or t (terabytes). <i>(FC specific)</i>
igroup create -f -t linux <i>initiator_group</i> <i>[WWPN...]</i>	Creates a new FC initiator group. Optionally, specify the initiator worldwide port names (<i>WWPN...</i>), or add them using the <code>igroup add</code> command.
igroup show <i>[initiator_group]</i>	Displays the initiator nodes in the specified initiator group. Omit <i>initiator_group</i> to see all igroups. <i>(FC or iSCSI)</i>
lun map <i>lun_path</i> <i>initiator_group</i> <i>[lun_id]</i>	Enables the specified LUN accessible to initiators in the specified igroup. Specify optional LUN ID, or take the lowest available value as the default value. <i>(FC or iSCSI)</i>
lun show [-v -m -c] [all mapped offline online unmapped] <i>lun_path</i> -g <i>initiator_group</i>	Displays general (-v), mapping (-m), or clone (-c) information about the specified set of LUNs. <i>(FC or iSCSI)</i>
lun online offline <i>lun_path...</i>	Enables or disables block-protocol access to the specified LUNs. <i>(FC or iSCSI)</i>
lun destroy [-f] <i>lun_path...</i>	Destroys the specified LUNs and all their data. Use -f if LUN is in use. <i>(FC or iSCSI)</i>
vol options <i>vol_name</i> nosnap on	Turns off scheduled Snapshot copies for a volume containing LUNs. It is best to enable the use of space reservations. <i>(iSCSI specific)</i>
igroup create -i [-t aix hpux default linux netware solaris vmware windows] <i>initiator_group [node...]</i>	Creates a new iSCSI initiator group. Optionally, specify the initiator node names (<i>node...</i>), or add them using the <code>igroup add</code> command.
igroup add <i>initiator_group</i> <i>node...</i>	Adds initiator nodes to the specified igroup. <i>(FC or iSCSI)</i>
lun move <i>lun_path</i> <i>to_lun_path</i>	Moves a LUN to a new path in the same volume. <i>(iSCSI specific)</i> Note: This command is used only in Data ONTAP 7.0.x.

Linux® Host Utilities 5.3 Quick Command Reference

General notes
You can also use the FilerView® GUI for many of the preceding commands (http://stor_sys_ip_address/na_admin).
The format of an iSCSI node name is <code>iqn.yyyy-mm.reverse_domain_name:anything</code> and is automatically set on the storage system (target) and each host (initiator). It is best to use the host name for the <i>anything</i> portion of the initiator node name.

Red Hat® Enterprise Linux	
Host configuration files	
<code>/etc/modprobe.conf</code>	Contains HBA driver parameter settings. (FC or iSCSI)
<code>/etc/fstab</code>	Lists the file systems to mount on FC or iSCSI LUNs.
<code>/etc/multipath.conf</code>	Lists local disks to exclude (blacklist) from multipathing and sets specific device parameters for NetApp® storage systems. (FC or iSCSI)
For Red Hat Enterprise Linux 5: <code>/etc/iscsi/initiatorname.iscsi</code> For Red Hat Enterprise Linux 4: <code>/etc/initiatorname.iscsi</code>	Contains the iSCSI node name of the initiator.
For Red Hat Enterprise Linux 5: <code>/etc/iscsi/iscsid.conf</code> For Red Hat Enterprise Linux 4: <code>/etc/iscsi.conf</code>	Lists most settings for the iSCSI initiator.
FC QLogic® HBA commands	
<code>scli -i</code>	Lists HBA attributes, including the WWPN.
<code>scli -c</code>	Lists all attributes for all available ports, including firmware and driver versions.
FC Emulex® HBA commands	
<code>/usr/sbin/hbanyware/hbacmd ListHBAs</code>	Lists HBA attributes, including the WWPN.
<code>/usr/sbin/hbanyware/hbacmd HBAAttrib wwpn</code>	Lists all attributes for the specified <i>wwpn</i> , including firmware and driver versions.
iSCSI QLogic® HBA commands	
<code>iscli -i</code>	Lists HBA attributes, including initiator names.
<code>iscli -c</code>	Lists all attributes for all available ports, including firmware and driver versions.
iSCSI service management commands	
<code>/etc/init.d/iscsi start</code>	Manually starts the iSCSI service on the Linux host.
<code>chkconfig iscsi on</code>	Configures the iSCSI service to start automatically.
Multipathing (dm-multipath) commands	
<code>/etc/init.d/multipathd start</code>	Manually starts the multipathing service on the Linux host. (FC or iSCSI)
<code>chkconfig --add multipathd</code> <code>chkconfig multipathd on</code>	Configures the multipathing service to start automatically. (FC or iSCSI)
<code>multipath -ll</code>	Displays the multipathing configuration. (FC or iSCSI)
<code>multipath -v3</code>	Creates the initial multipathing configuration. (FC or iSCSI)
<code>multipath -f <device_map></code>	Removes an existing LUN from the multipathing configuration. (FC or iSCSI)
<code>multipath -ll -v3 -d</code>	Displays the multipathing configuration with extended verbosity. (FC or iSCSI)
Accessing LUNs on host	
<code>sanlun lun show all</code>	Lists all the available LUNs. (FC or iSCSI)
<code>sanlun lun show -p</code>	Provides multipath information, for both native dm-multipath and Veritas Storage Foundation™ dynamic multipathing solutions. (FC or iSCSI)
<code>sanlun fcp show adapter -c</code>	Generates <code>igroup create</code> commands that you can run on the storage system to create an initiator group for this host. (FC specific)
<code>ls -lh /dev/mapper/</code>	Lists multipath devices generated for LUNs when using dm-multipath. (FC or iSCSI)
<code>fdisk device</code>	Partitions the LUN. <i>device</i> is the <code>/dev/sdx</code> name for the LUN. (FC or iSCSI)
<code>mkfs -V -t ext3 device</code>	Creates an ext3 file system on the partition or multipath <i>device</i> . For dm-multipath, creates the file system on the <code>/dev/mapper/device</code> . (FC or iSCSI)
<code>e2label device label</code>	Creates a persistent label for the file system. <i>device</i> is the partition, <i>label</i> is a unique string (maximum 16 characters). Not needed when using dm-multipath. (FC or iSCSI)

Linux® Host Utilities 5.3 Quick Command Reference

mount -a	Mounts all the file systems listed in /etc/fstab. (FC or iSCSI)
df -h	Lists all the mounted file systems. (FC or iSCSI)
For Red Hat Enterprise Linux 5: iscsiadm -m session iscsiadm -m session --sid=N --rescan iscsiadm -m session --rescan For Red Hat Enterprise Linux 4: /etc/init.d/iscsi reload	Gets the list of all the current sessions. Rescans a specific session; makes new LUNs visible on the host. Rescans all the sessions. Makes new LUNs visible on the host; does not affect other LUNs. (iSCSI specific)
/etc/init.d/iscsi restart	Discovers new LUNs when reload fails; interrupts all iSCSI sessions. (iSCSI specific)
For Red Hat Enterprise Linux 5: iscsiadm -m session --sid=0 -i For Red Hat Enterprise Linux 4: /sbin/iscsi-ls -l	Lists available LUNs as detected by the Linux host. (iSCSI specific)
Troubleshooting	
sanlun lun show all	Verifies that LUNs are visible on the host. (FC or iSCSI)
sanlun lun show -p	Verifies the multipath information. (FC or iSCSI)
sanlun fcp show adapter -v all	Verifies the host's WWPNs. (FC specific)
license (from storage system console)	Verifies that FC is licensed on the storage system. (FC or iSCSI)
lsmod grep qla lsmod grep lpfc	Verifies that the QLogic or Emulex driver is loaded on the host. (FC specific)
lsmod grep dm	Verifies that the dm-multipath driver is loaded on the host. (FC or iSCSI)
ping storage_system_IP_address (from host console) ping host_IP_address (from storage system console)	Verifies basic network connectivity between the storage system and host. (FC or iSCSI)
ifconfig (from storage system console and host console)	Verifies that network parameters are compatible on the host and storage system, especially duplex and jumbo frame (mtu) settings. (FC or iSCSI)
If using jumbo frames, verify that the jumbo frames are configured on all switches between the host and storage system.	
If using CHAP, verify the user names and passwords. The incoming values on the host are the outgoing values on the storage system. The incoming values on the storage system are the outgoing values on the host.	
Verifying the driver settings: - For QLogic HBA driver: Check the values in /sys/module/qla2xxx or /sys/module/qla2xxx/parameters/. - For Emulex HBA driver: Check the values in /sys/class/scsi_host/host<adapter number>.	
Check the log file on the storage system (/etc/messages) for error messages.	
Search the NetApp Service and Support Knowledgebase at https://now.netapp.com/eservice/SupportHome.jsp for information about the problem.	
Resources	
http://now.netapp.com	All NetApp documentation and software downloads.
http://now.netapp.com/NOW/knowledge/docs/san/fcp_iscsi_config/fcp_support.shtml	Support matrix.

SUSE® Linux Enterprise Server	
Host configuration files	
<code>/etc/modprobe.conf.local</code>	Contains HBA driver parameter settings. (FC or iSCSI)
<code>/etc/fstab</code>	Lists the file systems to mount on FC LUNs.
<code>/etc/multipath.conf</code>	Lists local disks to exclude (blacklist) from multipathing. This file is not present in SUSE Linux Enterprise Server 10, by default. You need to create it. (FC or iSCSI)
<u>For SUSE Linux Enterprise Server 10 and 11:</u> <code>/etc/iscsi/initiatorname.iscsi</code> <u>For SUSE Linux Enterprise Server 9:</u> <code>/etc/initiatorname.iscsi</code>	Contains the iSCSI node name of the initiator.
<u>For SUSE Linux Enterprise Server 10 and 11:</u> <code>/etc/iscsi/iscsid.conf</code> <u>For versions prior to SUSE Linux Enterprise Server 9:</u> <code>/etc/iscsi.conf</code>	Lists most settings for the iSCSI initiator.
<u>For SUSE Linux Enterprise Server 10 and 11:</u> <code>/etc/fstab</code> <u>For SUSE Linux Enterprise Server 9:</u> <code>/etc/fstab.iscsi</code>	Lists the file systems to mount on the iSCSI LUNs.
FC QLogic® HBA commands	
<code>scli -i</code>	Lists HBA attributes, including the WWPN.
<code>scli -c</code>	Lists all attributes for all available ports, including firmware and driver versions.
FC Emulex® HBA commands	
<code>/usr/sbin/hbanyware/hbacmd ListHBAs</code>	Lists HBA attributes, including the WWPN.
<code>/usr/sbin/hbanyware/hbacmd HBAAttrib <i>wwpn</i></code>	Lists all attributes for the specified <i>wwpn</i> , including firmware and driver versions.
iSCSI service management commands	
<u>For SUSE Linux Enterprise Server 10 and 11:</u> <code>/etc/init.d/open-iscsi {start stop}</code> <u>For SUSE Linux Enterprise Server 9:</u> <code>/etc/init.d/iscsi {start stop}</code>	Manually starts or stops the iSCSI service on the Linux host.
<u>For SUSE Linux Enterprise Server 10 and 11:</u> <code>chkconfig open-iscsi on</code> <u>For SUSE Linux Enterprise Server 9:</u> <code>chkconfig iscsi on</code>	Configures the iSCSI service to start automatically.
Multipathing (dm-multipath) commands	
<code>/etc/init.d/boot.multipath start</code> <code>/etc/init.d/multipathd start</code>	Manually starts the multipathing service on the Linux host. (FC or iSCSI)
<code>insserv boot.multipath multipathd</code>	Configures the multipath service to start automatically. (FC or iSCSI)
<code>multipath -ll</code>	Displays the multipathing configuration. (FC or iSCSI)
<code>multipath -v3</code>	Adds new LUNs to the multipath configuration. (FC or iSCSI)
<code>multipath -f <device_map></code>	Removes an existing LUN from the multipath configuration. (FC or iSCSI)
<code>multipath -ll -v3 -d</code>	Displays the multipathing configuration. (FC or iSCSI)

Veritas Storage Foundation	
Multipathing commands	
vxddmpadm stat restored	Displays the restore daemon statistics.
vxddmptune dmp_restore_interval 60	Sets the DMP restore interval to 60 seconds.
vxddmpadm getsubpaths ctrlr=<c1>	Lists all the DMP paths under the controller <c1>.
vxddmpadm getsubpaths dmpnodename=<DMP_nodename>	Displays all the paths to a particular LUN. The DMP_nodename can be in the OS-native or enclosure-based naming format.
vxddmpadm settune <dmp_tunable>=<value>	Sets the value for a particular DMP tunable.
vxddmpadm gettune all	Displays the DMP tunable parameters.
sanlun lun show -p	Provides multipath information, for both native dm-multipath and Veritas Storage Foundation dynamic multipathing solutions.
vxddmpadm list dmpnode	Displays information about dmpnode, such as LUN serial number, device attributes, and so on.
vxddmpadm list dmpnode dmpnodename=<dmp-device-name>	Displays information about a given dmpnode.
Accessing LUNs as Linux disk devices	
vxdisk list	Lists the LUNs available to the host.
vxdiskadm	Performs initialization, encapsulation, removal, replacement of disks, changing the disk naming scheme, and so on.
vxdisksetup	Configures the disk for use by Veritas Volume Manager.
vxdg	Manages disk groups under Veritas Volume Manager.
vxassist	Manages volumes under Veritas Volume Manager.
vxprint	Lists the volumes and disk group information.
sanlun lun show all	Lists available LUNs.
sanlun fcp show adapter -c	Generates igroup and create commands that you can run on the storage system to create an initiator group for this host.
ls -l /dev/vx/dmp	Lists multipath devices generated for LUNs when using Veritas multipathing.
mkfs -V -t vxfs volume	Creates a vxfs file system on the Veritas volume. The path for the Veritas volume is /dev/vx/dsk.
mount -t vxfs volume	Mounts a Veritas volume.
mount -a	Mounts all file systems listed in /etc/fstab.
df	Lists all mounted file systems.
Troubleshooting	
sanlun lun show all	Verifies that all the LUNs are visible on the host.
sanlun lun show -p all	Verifies the multipath information.
sanlun fcp show adapter -v all	Verifies the host's HBA WWPNS.
license (from storage system console)	Verifies that FC is licensed on the storage system.
lsmod grep qla lsmod grep lpfc	Verifies that the QLogic or Emulex driver is loaded on the host.
lsmod grep vxddmp	Verifies that the vxddmp module is loaded.
Check the log file on the storage system (/etc/messages) for error messages.	
Search the NetApp Service and Support Knowledgebase at https://now.netapp.com/eservice/SupportHome.jsp for information about the problem.	
Resources	
http://ftp.support.veritas.com/pub/support/products/VCS_for_WindowsNT/236522.pdf	Veritas Cluster Server command-line reference.
http://now.netapp.com	All NetApp documentation and software downloads.
http://now.netapp.com/NOW/knowledge/docs/san/fcp_iscsi_config/fcp_support.shtml	FC support matrix.