

Data ONTAP 4.3.4

- [Online Release Notices](#)
- [Online Documentation](#)
- [Software Download Instructions and Images](#)
- [FilerView 4.3.1](#)

Online Release Notices

Firmware Upgrade Requirement

Warning: [Read This Document](#)

Read the [Firmware](#) document carefully before upgrading your filer to Data ONTAP 4.0 or later software. You must install NetApp F220 and F330 Firmware 1.6 to run Data ONTAP 4.0 or later.

New Bug Fix for Data ONTAP 4.3.4

- 7950 Filer panic on swaps involving 9GB LP drives.

For more information about this bug, see [Bugs Online](#).

Online Documentation

After downloading the required software files, refer to the Data ONTAP 4.3.1 *Read Me First* document for installation instructions. Refer to the Data ONTAP 4.3.4 Read Me First for details about the bug fix.

- [Data ONTAP 4.3.4 Read Me First](#) (HTML, 3 KB)
- [Data ONTAP 4.3.1 Read Me First](#) (Acrobat, 214 KB)
- [Data ONTAP 4.3.3 Release Notes](#) (Acrobat, 10 KB)
- [Data ONTAP 4.3 System Administrator's Guide](#) (Acrobat, 2402 KB)
- [Data ONTAP 4.3 Configuration Guide](#) (Acrobat, 55 KB)

Software Download Instructions and Images

[Checksums](#)

Administration from UNIX host

F630, F500 Series	F200/F300 Series	1400, 1300, 450, 400
Boot Diskette (1.1MB)	Boot Diskette (1.1MB)	Boot Diskette (1.1MB)
System Files (1.9MB)	System Files (1.8MB)	System Files (1.8MB)

Administration from Windows PC

F630, F500 Series	F200/F300 Series	1400, 1300, 450, 400
Boot Diskette	Boot Diskette	Boot Diskette

(1.1MB)	(1.1MB)	(1.1MB)
System Files (1.6MB)	System Files (1.5MB)	System Files (1.5MB)

[FilerView 4.3.1](#)

FilerView consists of a collection of HTML, Java, and Javascript files that you install on your filer. FilerView enables you to inspect the status of the filer or issue commands to the filer from your Web browser.