

ApplianceWatch for Microsoft® Operations Manager 1.1 **Installation and Setup Guide for MOM 2005**

Network Appliance, Inc.
495 East Java Drive
Sunnyvale, CA 94089 USA
Telephone: +1 (408) 822-6000
Fax: +1 (408) 822-4501
Support telephone: +1 (888) 4-NETAPP
Documentation comments: doccomments@netapp.com
Information Web: <http://www.netapp.com>

210-03660_A0
March 2007

Copyright and trademark information

Copyright information

Copyright © 1994–2007 Network Appliance, Inc. All rights reserved. Printed in the U.S.A.

No part of this document covered by copyright may be reproduced in any form or by any means—graphic, electronic, or mechanical, including photocopying, recording, taping, or storage in an electronic retrieval system—without prior written permission of the copyright owner.

Portions of this product are derived from the Berkeley Net2 release and the 4.4-Lite-2 release, which are copyrighted and publicly distributed by The Regents of the University of California.

Copyright © 1980–1995 The Regents of the University of California. All rights reserved.

Portions of this product are derived from NetBSD, which is copyrighted by Carnegie Mellon University.

Copyright © 1994, 1995 Carnegie Mellon University. All rights reserved. Author Chris G. Demetriou.

Permission to use, copy, modify, and distribute this software and its documentation is hereby granted, provided that both the copyright notice and its permission notice appear in all copies of the software, derivative works or modified versions, and any portions thereof, and that both notices appear in supporting documentation.

CARNEGIE MELLON ALLOWS FREE USE OF THIS SOFTWARE IN ITS “AS IS” CONDITION. CARNEGIE MELLON DISCLAIMS ANY LIABILITY OF ANY KIND FOR ANY DAMAGES WHATSOEVER RESULTING FROM THE USE OF THIS SOFTWARE.

Software derived from copyrighted material of The Regents of the University of California and Carnegie Mellon University is subject to the following license and disclaimer:

Redistribution and use in source and binary forms, with or without modification, are permitted provided that the following conditions are met:

1. Redistributions of source code must retain the above copyright notices, this list of conditions, and the following disclaimer.
2. Redistributions in binary form must reproduce the above copyright notices, this list of conditions, and the following disclaimer in the documentation and/or other materials provided with the distribution.
3. All advertising materials mentioning features or use of this software must display the following acknowledgment:

This product includes software developed by the University of California, Berkeley and its contributors.
4. Neither the name of the University nor the names of its contributors may be used to endorse or promote products derived from this software without specific prior written permission.

THIS SOFTWARE IS PROVIDED BY THE REGENTS AND CONTRIBUTORS “AS IS” AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE REGENTS OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER

IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

Software derived from copyrighted material of Network Appliance, Inc. is subject to the following license and disclaimer:

Network Appliance reserves the right to change any products described herein at any time, and without notice. Network Appliance assumes no responsibility or liability arising from the use of products described herein, except as expressly agreed to in writing by Network Appliance. The use or purchase of this product does not convey a license under any patent rights, trademark rights, or any other intellectual property rights of Network Appliance.

The product described in this manual may be protected by one or more U.S. patents, foreign patents, or pending applications.

RESTRICTED RIGHTS LEGEND: Use, duplication, or disclosure by the government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.277-7103 (October 1988) and FAR 52-227-19 (June 1987).

Trademark information

NetApp, the Network Appliance logo, the bolt design, NetApp—the Network Appliance Company, DataFabric, Data ONTAP, FAServer, FilerView, MultiStore, NearStore, NetCache, SecureShare, SnapManager, SnapMirror, SnapMover, SnapRestore, SnapVault, SyncMirror, and WAFL are registered trademarks of Network Appliance, Inc. in the United States, and/or other countries. gFiler, Network Appliance, SnapCopy, Snapshot, and The Evolution of Storage are trademarks of Network Appliance, Inc. in the United States and/or other countries and registered trademarks in some other countries. ApplianceWatch, BareMetal, Camera-to-Viewer, ComplianceClock, ComplianceJournal, ContentDirector, ContentFabric, EdgeFiler, FlexClone, FlexVol, FPolicy, HyperSAN, InfoFabric, LockVault, Manage ONTAP, NOW, NOW NetApp on the Web, ONTAPI, RAID-DP, RoboCache, RoboFiler, SecureAdmin, Serving Data by Design, SharedStorage, Simulate ONTAP, Smart SAN, SnapCache, SnapDirector, SnapDrive, SnapFilter, SnapLock, SnapMigrator, SnapSuite, SnapValidator, SohoFiler, vFiler, VFM, Virtual File Manager, VPolicy, and Web Filer are trademarks of Network Appliance, Inc. in the United States and other countries. NetApp Availability Assurance and NetApp ProTech Expert are service marks of Network Appliance, Inc. in the United States. Spinnaker Networks, the Spinnaker Networks logo, SpinAccess, SpinCluster, SpinFS, SpinHA, SpinMove, and SpinServer are registered trademarks of Spinnaker Networks, LLC in the United States and/or other countries. SpinAV, SpinManager, SpinMirror, SpinRestore, SpinShot, and SpinStor are trademarks of Spinnaker Networks, LLC in the United States and/or other countries.

Apple is a registered trademark and QuickTime is a trademark of Apple Computer, Inc. in the United States and/or other countries. Microsoft is a registered trademark and Windows Media is a trademark of Microsoft Corporation in the United States and/or other countries. RealAudio, RealNetworks, RealPlayer, RealSystem, RealText, and RealVideo are registered trademarks and RealMedia, RealProxy, and SureStream are trademarks of RealNetworks, Inc. in the United States and/or other countries.

All other brands or products are trademarks or registered trademarks of their respective holders and should be treated as such.

Network Appliance is a licensee of the CompactFlash and CF Logo trademarks.

Network Appliance NetCache is certified RealSystem compatible.

Table of Contents

	Preface	vii
Chapter 1	Overview of ApplianceWatch for MOM.	1
	What ApplianceWatch for MOM is	2
Chapter 2	Installing ApplianceWatch for MOM	3
	Before you begin	4
	Configuring the global security setting for MOM 2005	8
	Installing the ApplianceWatch for MOM support files	9
	Installing the ApplianceWatch for MOM management pack	13
	Verifying the management pack installation	14
Chapter 3	Configuring the Storage Systems and Servers	21
	Configuring storage systems	22
	Configuring DataFabric Manager Servers	26
Appendix A	SNMP Event Severity Mappings	31

Preface

About this guide

This guide describes how to install the ApplianceWatch for Microsoft Operations Manager (MOM) management pack. The management pack contains the required files and registry settings to support NetApp storage system and DataFabric® Manager monitoring via MOM.

Before installing this product, you must have:

- ◆ Ensured that your configuration is supported by referring to the *Compatibility and Configuration Guide for NetApp's FCP and iSCSI Products*, available on the NetApp on the Web™ (NOW) site at http://now.netapp.com/NOW/knowledge/docs/san/fcp_iscsi_config/.
- ◆ your storage system according to the instructions in the documentation for your specific storage system.
- ◆ Configured your storage system according to the instructions in the following documents:
 - ❖ *Data ONTAP® Software Setup Guide*
 - ❖ *iSCSI Support Kit* for your specific host
 - ❖ *SAN Setup Overview for FCP*
 - ❖ *SAN Host Attach Kit for Fibre Channel Protocol* for your specific host
 - ❖ Any SAN switch documentation for your specific FCP switch, which you can find at <http://now.netapp.com/NOW/knowledge/docs/san/>

Audience

This guide is for system and network administrators responsible for monitoring NetApp storage systems and DataFabric Manager servers via the MOM.

Terminology

This guide uses the following terms:

- ◆ NetApp storage products (filers, FAS appliances, and NearStore® systems) are all *storage systems*—also sometimes called filers or storage appliances.
- ◆ *Enter* refers to pressing one or more keys on the keyboard and then pressing the Enter key.
- ◆ *Type* refers to pressing one or more keys on the keyboard.

Command conventions

In examples that illustrate commands executed on a UNIX workstation, the command syntax and output shown in this guide might differ from what you see on your display, depending on your version of UNIX.

**Keyboard
conventions**

When describing key combinations, this guide uses the hyphen (-) to separate individual keys that you press at the same time. For example, *Ctrl-D* means pressing the Control and D keys simultaneously. This guide uses the term *Enter* to refer to the key that generates a carriage return, although the key is named Return on some keyboards.

**Typographic
conventions**

The following table describes typographic conventions used in this guide.

Convention	Type of information
<i>Italic font</i>	Words or characters that require special attention. Placeholders for information you must supply. For example, if the guide says to enter the <code>arp -d <i>hostname</i></code> command, you enter the characters <i>arp -d</i> followed by the actual name of the host. Book titles in cross-references.
Monospaced font	Command and daemon names. Information displayed on the system console or other computer monitors. The contents of files.
Bold monospaced font	Words or characters you type. What you type is always shown in lowercase letters, unless you must type it in upper case.

Special messages

This guide contains special messages that are described as follows:

Note

A note contains important information that helps you install or operate the system efficiently.

CAUTION

An attention contains instructions that you must follow to avoid damage to the equipment, a system crash, or loss of data.

About this chapter

This chapter provides a brief overview of the ApplianceWatch for MOM management pack, and lists the prerequisites for installing it.

Topics in this chapter

This chapter discusses the following topic(s):

- ◆ [“What ApplianceWatch for MOM is”](#) on page 2

What ApplianceWatch for MOM is

What is ApplianceWatch for MOM?

MOM is an enterprise level software tool designed to monitor events, collect performance statistics, and report alert conditions across a Microsoft OS-based enterprise

ApplianceWatch for MOM is designed to be installed on the MOM server and to interpret SNMP traps from NetApp systems, thus allowing MOM's standard event classification and response rules to be applied to NetApp systems.

Support matrix for ApplianceWatch for MOM includes the following:

- ◆ Data ONTAP 7.2.x and earlier releases
- ◆ DatFabric Manager Server 3.5 and releases
- ◆ MOM 2000 and MOM 2005

ApplianceWatch for MOM components

The ApplianceWatch for MOM management pack contains the required files and registry settings to support NetApp storage systems and DataFabric Manager server monitoring via MOM. Follow the instructions in this document to install the management pack.

The ApplianceWatch for MOM installation package installs the following files on the MOM server:

- ◆ dfm.mof - converted NetApp DataFabric Manager MIB file.
- ◆ netapp.mof - converted NetApp storage system MIB file.
- ◆ license.txt - licensing information for ApplianceWatch for MOM..
- ◆ netapp.akm - ApplianceWatch for MOM management pack.
- ◆ installMOF.bat - batch file to register dfm.mof and netapp.mof files with Windows Management Instrumentation (WMI). Microsoft's mofcomp.exe must be installed on the computer.
- ◆ uninstall.exe - uninstall program to remove NetApp support for MOM.

About this chapter This chapter describes how to install ApplianceWatch for MOM.

Topics in this chapter This chapter discusses the following topic:

- ◆ [“Before you begin”](#) on page 4
- ◆ [“Configuring the global security setting for MOM 2005”](#) on page 8
- ◆ [“Installing the ApplianceWatch for MOM support files”](#) on page 9
- ◆ [“Installing the ApplianceWatch for MOM management pack”](#) on page 13
- ◆ [“Verifying the management pack installation”](#) on page 14

Before you begin

Prerequisites

Before installing the management pack, ensure you meet the following prerequisites:

- ◆ MOM server is installed on the computer.
- ◆ You have administrative privileges on the computer on which the management pack is to be installed.
- ◆ You have the privileges required to provision the NetApp storage systems and DataFabric Manager servers being monitored via ApplianceWatch for MOM.
- ◆ Simple Network Management Protocol (SNMP) and WMI SNMP Provider are installed on the MOM server, and the SNMP trap service is properly configured.

The use of a registry key for the MOM Server

To enable MOM to monitor NetApp storage systems and DataFabric Manager servers, a registry key is required on the MOM server. This registry key is created during the MOM management pack installation.

MOM uses this registry key to discover NetApp *Computer Groups*, which enable the MOM server to monitor NetApp storage systems and DataFabric Manager servers.

The registry key created by this installation package is **HKEY_LOCAL_MACHINE\SOFTWARE\Network Appliance\ApplianceWatch for MOM**, and contains the following values:

- ◆ dfm - dfm.mof
- ◆ netapp - netapp.mof
- ◆ management pack - netapp.akm
- ◆ installpath - <install directory>
- ◆ version - <version>

Provisioning SNMP and SNMP trap services

Before installing ApplianceWatch for MOM, you must install SNMP and SNMP trap services. You should:

1. Verify that these items are installed. See [“Verifying SNMP and SNMP trap services are installed”](#) on page 5.

2. Install the services on the MOM server, if they are not already installed. See [“Adding SNMP and WMI SNMP Provider to the MOM server”](#) on page 5.
3. Configure the SNMP service. See [“Configuring the SNMP service”](#) on page 5.
4. Configure SNMP trap service. See [“Configuring the SNMP trap service”](#) on page 6.

Verifying SNMP and SNMP trap services are installed: Follow these instructions to determine if SNMP and SNMP trap services are already installed on the MOM server.

Step	Action
1	From the MOM server desktop, right-click My Computer and select Manage.
2	Expand Services and Applications; then click Services.
3	Verify that SNMP Service and SNMP Trap Service appear in the list of services. If they are not installed, see “Adding SNMP and WMI SNMP Provider to the MOM server” on page 5 to install them.

Adding SNMP and WMI SNMP Provider to the MOM server: Follow these instructions to add SNMP and WMI SNMP Provider to the MOM server if they are not already installed.

Step	Action
1	Open the Add/Remove software control panel.
2	Select the Add/Remove Windows components.
3	Select Management and Monitoring Tools.
4	Select Simple Network Management Protocol and WMI SNMP Provider.
5	Click OK.

Configuring the SNMP service: Follow these instructions to install the SNMP service on the MOM server.

Step	Action
1	From the MOM server desktop, right-click My Computer and select Manage.
2	Expand Services and Applications; then click Services.
3	Right-click SNMP Trap Service and select Properties.
4	Click the General tab.
5	Select the Automatic startup type.
6	Click the Traps tab.
7	Type <i>public</i> in the Community Name drop-down list and select Add to List.
8	Click the Security tab.
9	Select Accept SNMP Packets from any Host.
10	Click Apply; then click OK.

Configuring the SNMP trap service: Follow these instructions to install the SNMP trap service on the MOM server.

Step	Action
1	From the MOM server desktop, right-click My Computer and select Manage.
2	Expand Services and Applications; then click Services.
3	Right-click SNMP Trap Service and select Properties.
4	Click the General tab.
5	Select the Automatic startup type.
6	Click Apply; then click OK.


Installation process overview

The ApplianceWatch for MOM installation process consists of the following main steps:

1. Downloading the ApplianceWatch for MOM management pack from NetApp on the Web (NOW).
2. Configuring the global security setting for MOM 2005.
3. Installing the ApplianceWatch for MOM support files.
4. Installing the ApplianceWatch for MOM management pack.
5. Configuring the appropriate devices to forward all SNMP traps to the MOM server:
 - ❖ To directly monitor storage systems from MOM, configure each storage system to forward all SNMP traps to the MOM server.
 - ❖ To monitor the storage systems via DataFabric Manager server, configure DataFabric Manager server to forward all SNMP traps to the MOM server.


Configuring the global security setting for MOM 2005


Before installing the management pack for MOM 2005, modify the required global security setting in the MOM Administrator Console by following this procedure.

Step	Action
1	Open the MOM 2005 Administrator Console.
2	In the left pane under Management Packs, expand the Administration folder.
3	Select Global Settings.
4	In the right pane, right-click Security and select Properties from the pop-up menu. Result: The Security box appears. 
5	Click the Security tab and clear the Disable execution of custom responses on Management Servers check box.
6	Click Apply; then click OK.


Installing the ApplianceWatch for MOM support files

Follow these steps to install the ApplianceWatch for MOM support files.

Step	Action
1	Copy the awMOM2005setup-1-1-win.exe file to a directory on the computer running MOM server.
2	Double-click awMOM2005setup-1-1-win.exe. Result: The Choose Components dialog box appears. 
3	Select Network Appliance MOF Registration. Result: The Netapp .mof files are registered with WMI. Note _____ The MOM server will not be able to monitor NetApp storage systems and DataFabric Manager servers without registering the .mof files.

Step	Action
4	Click Next. Result: The Choose Install Location dialog box appears. 
5	Type the install directory in the Destination Folder field, or click Browse to select a directory.
6	Click Install. Result: The NetApp support files are installed.

Step	Action
7	Click Show Details to view the installed files, and click Next to continue. Result: The Completing the NetApp MOM Support Setup Wizard dialog box appears. 
8	Select Show Readme to view the Readme file; then click Finish.

Step	Action
9	Verify that the installation is complete by opening Windows Explorer and navigating to the install directory. The following files should appear. 

Installing the ApplianceWatch for MOM management pack

After you install the NetApp support files, follow these steps to install the ApplianceWatch for MOM management pack.

Step	Action
1	Open the MOM Administrator Console.
2	Right-click Management Packs and select Import/Export Management Pack from the pop-up menu. Click Next. Result: The Import or Export Management Packs dialog box appears.
3	Select Import Management Packs and/or reports, click Next. Result: The Select a Folder and Choose Import Type dialog box appears.
4	Enter the path where you installed the NetApp support files, or click Browse and locate the correct path; the default is c:\Program Files\Network Appliance\ApplianceWatch for MOM . Click Next. Result: The Select Management Packs dialog box appears, and the file NetApp.akm appears in the Please select one or more Management Packs to import dialog box.
5	Select NetApp.akm , then select Update existing Management Pack and Backup existing Management Pack. Click Next.
6	Verify that you have selected to install NetApp.akm and click Finish to install the management pack.

Verifying the management pack installation

After you install the ApplianceWatch for MOM management pack, follow these steps to verify the installation.

The NetApp Management Pack contains the following entries in the MOM Administrator Console. Verify that each entry exists after installation.

- ◆ Computer Group
- ◆ Rules Group
- ◆ Scripts
- ◆ Computer Attributes
- ◆ Providers

Verifying the Computer Group entries

Follow these steps to verify that the NetApp Computer Group entries exist. The Computer Group identifies how MOM discovers and manages NetApp storage systems and DataFabric Manager servers.


Step	Action
1	Open the MOM 2005 Administrator Console.
2	Expand the Management Packs item in the left pane.
3	Expand the Computer Groups folder. Result: The list of computer groups appears.

Step	Action
4	Verify that the NetApp DataFabric Manager & Filers entry appears.

Verifying the Rules Group entries

Follow these steps to verify that the NetApp rules are installed. The rules developed for NetApp are used to execute a processing script when MOM receives an event (SNMP trap) from a DataFabric Manager server or storage system.

Step	Action
1	In the MOM 2005 Administrator Console, expand the Management Packs item.
2	Expand the Rules Groups folder.


Step	Action
3	Expand the Network Appliance DataFabric Manager & Filer folder. Result: The NetApp rules appear. 

Verifying the Script entries

Follow these steps to verify that the NetApp script is installed. This script is used to process the SNMP trap events that are specific to NetApp by converting them into the appropriate MOM alert and inserting the alert into the MOM database.

Step	Action
1	In the MOM 2005 Administrator Console, expand the Management Packs item.
2	Select Scripts. Result: The list of scripts appears in the right pane.

Step	Action
3	Verify that the NetApp Alert Generator script appears in the right pane.



The screenshot shows the MOM 2005 Administrator Console. The left pane displays a tree view with 'Console Root' expanded, showing 'Information Center (YOUR-KCSKTEZ246)' and 'Operations'. Under 'Operations', 'Management Packs' is expanded, showing 'Computer Groups', 'Discovered Groups', 'Rule Groups', 'Override Criteria', 'Tasks', 'Notification', 'Scripts', 'Computer Attributes', 'Providers', and 'Administration'. The 'Scripts' folder is selected. The right pane displays a table of scripts:


Name	Language	Description
MOM Action Account Password Expiration Check	VBScript	Generates an e...
MOM Agent Service Discovery	VBScript	Performs Serv...
MOM Database State Monitoring	VBScript	Collects state f...
MOM Logging Level Verification	VBScript	Detects when t...
MOM Mail alerts for forwarding to MOM Master management group	VBScript	This script chan...
MOM Test End to End Monitoring	VBScript	Verifies MOM e...
MOM Virtual Service Discovery	VBScript	Performs disco...
Appliance DataFabric Manager & Filr Alert Generator	VBScript	This script pro...

Verifying the Computer Attribute entries

Follow these steps to verify that the NetApp MOM Support computer attribute is installed. This attribute is a registry value that is created when you install the NetApp for MOM support files. It allows the MOM server to discover the NetApp computer group.

See [“What ApplianceWatch for MOM is”](#) on page 2 for more information.


Step	Action
1	In the MOM 2005 Administrator Console, expand the Management Packs item.
2	Select Computer Attributes. Result: The list of computer attributes appears in the right pane.

Step	Action																																								
3	Verify that the NetApp MOM Support entry appears in the right pane.  The screenshot shows the MOM 2005 Administrator Console. On the left, the 'Providers' folder is expanded under 'Management Packs'. On the right, a list of providers is displayed with columns for Name, Type, Enabled, and Description. The 'Network Appliance MOM Support' entry is highlighted with a red box. <table><thead><tr><th>Name</th><th>Type</th><th>Enabled</th><th>Description</th></tr></thead><tbody><tr><td>Microsoft Operations Manager 2005 Agent</td><td>string</td><td>Yes</td><td>Collects MOM Agent version information</td></tr><tr><td>Microsoft Operations Manager 2005 Applied Software Upd...</td><td>string</td><td>Yes</td><td>Collects the applied software update</td></tr><tr><td>Microsoft Operations Manager 2005 Database Server</td><td>string</td><td>Yes</td><td>Collects MOM Database Server version</td></tr><tr><td>Microsoft Operations Manager 2005 Product Connector Se...</td><td>boolean</td><td>Yes</td><td>Checks if the MOM Product Connector is installed</td></tr><tr><td>Microsoft Operations Manager 2005 Reporting Server</td><td>string</td><td>Yes</td><td>Collects MOM Reporting Server version</td></tr><tr><td>Microsoft Operations Manager 2005 Reporting Database S...</td><td>boolean</td><td>Yes</td><td>Checks if the MOM Reporting Database is installed</td></tr><tr><td>Microsoft Operations Manager 2005 Server</td><td>string</td><td>Yes</td><td>Collects MOM Server version information</td></tr><tr><td>Microsoft Windows Current Version</td><td>string</td><td>Yes</td><td>Detects the Windows Current Version</td></tr><tr><td>Network Appliance MOM Support</td><td>boolean</td><td>Yes</td><td>Detects the support for Network Appliance</td></tr></tbody></table>	Name	Type	Enabled	Description	Microsoft Operations Manager 2005 Agent	string	Yes	Collects MOM Agent version information	Microsoft Operations Manager 2005 Applied Software Upd...	string	Yes	Collects the applied software update	Microsoft Operations Manager 2005 Database Server	string	Yes	Collects MOM Database Server version	Microsoft Operations Manager 2005 Product Connector Se...	boolean	Yes	Checks if the MOM Product Connector is installed	Microsoft Operations Manager 2005 Reporting Server	string	Yes	Collects MOM Reporting Server version	Microsoft Operations Manager 2005 Reporting Database S...	boolean	Yes	Checks if the MOM Reporting Database is installed	Microsoft Operations Manager 2005 Server	string	Yes	Collects MOM Server version information	Microsoft Windows Current Version	string	Yes	Detects the Windows Current Version	Network Appliance MOM Support	boolean	Yes	Detects the support for Network Appliance
Name	Type	Enabled	Description																																						
Microsoft Operations Manager 2005 Agent	string	Yes	Collects MOM Agent version information																																						
Microsoft Operations Manager 2005 Applied Software Upd...	string	Yes	Collects the applied software update																																						
Microsoft Operations Manager 2005 Database Server	string	Yes	Collects MOM Database Server version																																						
Microsoft Operations Manager 2005 Product Connector Se...	boolean	Yes	Checks if the MOM Product Connector is installed																																						
Microsoft Operations Manager 2005 Reporting Server	string	Yes	Collects MOM Reporting Server version																																						
Microsoft Operations Manager 2005 Reporting Database S...	boolean	Yes	Checks if the MOM Reporting Database is installed																																						
Microsoft Operations Manager 2005 Server	string	Yes	Collects MOM Server version information																																						
Microsoft Windows Current Version	string	Yes	Detects the Windows Current Version																																						
Network Appliance MOM Support	boolean	Yes	Detects the support for Network Appliance																																						

Verifying the Provider entries

Follow these steps to verify that the NetApp Provider entry is installed. This provider uses the WMI Event base provider and then selects from SNMP V1 notifications from the WMI SNMP namespace.

Step	Action
1	In the MOM 2005 Administrator Console, expand the Management Packs item.
2	Select Providers. Result: The list of providers appears in the right pane.

Step	Action
3	Verify that the NetApp Trap Catcher entry appears in the right pane.  The screenshot shows the MOM 2005 Administrator Console. The left pane displays a tree view of the console structure, including sections like Console Root, Microsoft Operations Manager (YOUR-PCGKTE724M), Information Center, Operations, Management Packs, Computer Groups, Discovered Groups, Rule Groups, Override Criteria, Tasks, Notification, Scripts, Computer Attributes, Providers, Administration, Computers, Console Scopes, Global Settings, and Product Connectors. The right pane displays a list of items, categorized by Type and Name. The 'BIM Events' category is selected, and the 'Network Appliance Trap Catcher' entry is highlighted. The list includes various performance counters and events, such as MOM Server Cb Perf Insert Avg Time, MOM Server Cb Perf Insert Inc Rate, MOM Server Queue Space Percent Used, MOM to MOM Connector Service-New Alert Forwarding Rate, MOM Raw Agent Bytes Received, MOM Raw Agent Bytes Transmitted, MOM-Schedule every 1 days synchronize, MOM-Schedule every 1 days synchronize at 04:00, MOM-Schedule every 1 days synchronize at 05:00, MOM-Schedule every 30 minutes synchronize at 00:05, MOM-Schedule every 30 minutes synchronize at 00:10, MOM-Schedule every 30 minutes synchronize at 00:15, MOM-Server Channel Errors, MOM-Server Channel Errors, MOM-Server Fragmented Hits, MOM-Server I/O Timeouts, MOM-Server Legacy Connections, MOM-Server Listen Queue Length, MOM-Server Raw Bytes Received, MOM-Server Raw Bytes Transmitted, MOM-Server Total Connections, Performance Measuring: Process\%Processor Time\MOMService - 1 hour, Performance Measuring: Process\Handle Count\MOMService - 1 hour, Performance Measuring: Process\Private Bytes\MOMService - 1 hour, Process-% Processor Time-MOMHost - 1.0-hours, Process-Elapsed Time-MOMService-1.0-hours, Process-Elapsed Time-System-1.0-hours, Process-Handle Count-MOMHost-1.0-hours, Process-Private Bytes-MOMHost-1.0-hours, Script-generated Data, and Security.

About this chapter This chapter describes how to configure your storage systems and DataFabric Manager servers to forward their SNMP traps to the MOM server.

Topics in this chapter This chapter discusses the following topic:

- ◆ “[Configuring storage systems](#)” on page 22
- ◆ “[Configuring DataFabric Manager Servers](#)” on page 26

Configuring storage systems

There are two ways to configure your storage systems:

- ◆ Use the CLI.
- ◆ Use the FilerView® administration tool.

Using the CLI to configure storage systems

After you connect to the storage system via the CLI, follow these steps to set the SNMP settings. Type `snmp options` at the command prompt for a list of options:

```
usage: snmp options
Options are:

                                (no option => display current settings)
authtrap    [ 0|1 ]            (0 => disabled, 1 => enabled)
community   [ add ro <community> ]
community   [ delete { all | ro <community> } ]
contact     [ <contact> ]
init        [ 1 ]              (0 => uninitialized, 1 => initialized)
location    [ <location> ]
traphost    [ add|delete <hostname|ipaddress> ]
traps       [ enable|disable|reset|delete ] [ <trapname> ]
traps       <trapname>.<parm> <value>
traps       walk <prefix>
traps       load <filename>
```

Note _____
Use single quotes (for example, 'abc def') to enclose strings that include spaces or tabs.


Step	Action
1	From the command prompt, enter the following command: <code>snmp init</code>
2	Enter the following command: <code>snmp authtrap 1</code>
3	Enter the following command: <code>snmp contact <contact person></code>

Step	Action
4	Enter the following command: snmp community add ro public
5	Enter the following command: snmp location <filer location>
6	Enter the following command: snmp trapshot add <MOM server IP>
7	Enter the following command: snmp Example: Dax*> snmp contact: <contact person> location: <filer location> authtrap: 1 community: ro public traphost: MOM server IP (MOM server IP) < MOM server IP > init: 1
8	Repeat these steps for each storage system.

Using FilerView to configure storage systems

To configure storage systems via FilerView, you can either connect through your Web browser or access FilerView through the DataFabric Manager application.

Step	Action
1	Open FilerView.
2	From the left pane, click SNMP.


Step	Action
3	Under SNMP, click Configure. Result: The Configure SNMP options appear. 
4	Select Yes from the SNMP Enabled drop-down list.
5	Select Yes from the Traps Enabled drop-down list.
6	Select Yes from the Auth Traps drop-down list.
7	Type a contact name in the Contact field.
8	Type the location of the storage system in the Location field.
9	In the Communities section, select an open row and select Read Only from the drop-down list; then type Public in the text box.


Step	Action
10	In the Traphosts section, type the MOM server IP address in the text box in the same row from Step 9 (see the illustration above, for example).
11	Click Apply. Result: The configuration settings are saved.
12	Repeat these steps for each storage system.

Configuring DataFabric Manager Servers

To enable MOM to monitor Network Appliance DataFabric Manager servers, you must configure the DataFabric Manager server to forward its events to MOM via SNMP traps.


Selecting the configuration settings


Step	Action
1	Connect to the DataFabric Manager server via your Web browser.
2	Click the Alarms menu at the top of the window.
3	Click Advanced Version near the bottom of the window. Result: The Alarms options appear. 


Step	Action
4	Under Select Event By, select Severity, then select All from the drop list. Result: The DataFabric Manager server will forward all events to the MOM server.
5	In the SNMP Trap Hosts field, enter the community string, IP address, and trap port for the MOM server. Note_____ The default community string is <i>public</i> and the default trap port is <i>162</i>. _____ Example: public@<MOM Server IP address>:162
6	Click Add. Result: The new details appear at the bottom of the window. 

Testing the configuration settings

To verify that the DataFabric Manager server is configured correctly, you can send a test SNMP trap to the MOM server. Follow these steps to test the configuration settings.

Step	Action
1	Click Test at the bottom of the window, as shown in the previous illustration. Result: The Test Alarm window appears. 
2	Click Test. Result: A test SNMP trap is sent to the MOM server.
3	Open the MOM Operator Console and expand the All Event Views folder.

Step	Action
4	Select Events. Result: The test SNMP event appears.  The screenshot shows the Microsoft Operations Manager 2005 - Operator Console. The left pane displays the 'Event Views' tree with 'All Event Views' expanded. The main pane shows a list of events with columns for Time, Domain, Computer, Description, Source, and Category. The events are all 'Success' and 'RTTPOE' type, with descriptions like 'YOUR-40CKTET..._CLASS=SimpleNotification'. The 'Event Details' pane for a selected event shows properties such as Description, Domain, Computer, Time, Type, Provider Name, Event Number, Provider Type, Source, Category, Basic Alert, Consolidated, To, and Event ID. The event ID is 'bba6163-46b-40c-6226-912149c175f6'.
5	In the MOM Operator Console, open the Alert View and expand the All Alert Views folder.

Step	Action
6	Select Alerts. Result: The Information alert appears in the right pane, describing the test event. 

Understanding how NetApp SNMP events map to MOM events

The current MOM management pack allows the MOM server to process all SNMP traps generated by both the DataFabric Manager servers and storage systems. You can simultaneously monitor both the devices. Keep in mind that if you have a DataFabric Manager server monitoring storage systems and you are also individually monitoring one of the storage systems, you will receive duplicate alerts.

The follow tables list the NetApp storage system and DataFabric Manager severities and their corresponding MOM severities.

DataFabric Manager Event Severity	MOM Severity
1 (Normal)	Success
2 (Information)	Information
3 (Warning)	Warning
4 (Error)	Error
5 (Critical)	Critical
6 (Emergency)	Critical

Storage System SNMP Severity	MOM Severity
1 (Emergency)	Critical
2 (Alert)	Critical
3 (Critical)	Critical
4 (Error)	Error
5 (Warning)	Warning
6 (Notification)	Information
7 (Information)	Information
8 (Debug)	Information

